

How to apply Anti-Seize Lubricant to iMX end-mills

- 1) Before installing head, please clean the dirt and oil off the taper, end faces of iMX-head and holder with clean cloth. (A new iMX-head is coated with rust preventive oil, even a new head must be cleaned)
- 2) Apply a small amount of anti-seize lubricant only on the back end portion of threads of iMX-head. Please be careful of the amount of lubricant to prevent lubricant reaching the taper face, when installing to holder, as lubricant may affect the performance of the coupling mechanism.
- 3) Be careful not to attach the lubricant to internal taper face of the holder, when installing the iMX-head.

