

**A**

Screw  
GY06013M x 1pc.

TKY15D TKY30R  
Wrenches

Screws  
TS407 x 4pcs.

①

GYDL\*\*\*90\* **M20R**

**Modular Blade**

Use blade)

GYM20R/L-D10  
GYM20R/L-E10  
GYM20R/L-F10  
GYM20R/L-G12  
GYM20R/L-H12

GY **M20R** A - **F**10

②                      ③

---

**Insert**

④

GY2M0300 **F**040N-MS  
GY2M0318 **F**030N-GM

Note1) ③ and ④ are changed by the insert size.

**B**

Screws : TS407  
Wrench: **TKY15D**  
Torque : 3.5 Nm  
31 lbf-in

Side Screws  
(2 screws)

Note2) ① and ② should be matched.

**C**

Screws : TS407  
Wrench: **TKY15D**  
Torque : 3.5 Nm  
31 lbf-in

Front Screws  
(2 screws)

Note3)  
Please tighten the TS407 screws  
in order of [Side screws] → [Front screws].

**D**

Note4)  
Please clean the insert-seat  
before installing the insert.

Note5)  
③ and ④ should be matched.  
(See caption A)

**E**

Screw : GY06013M  
Wrench : TKY30R  
Torque : 6.0 Nm  
53 lbf-in

Note6)  
Don't tighten this screw [GY06013M]  
without installing the insert.  
Modular blade might be damaged.

**F**

Complete.

Note7) [GY06013M] is inclined.  
Ensure that the wrench is perpendicular  
to the screw tightening.

**Attention)** Be careful enough so that there is a sharp part in the product when you set it.