





INDEX

INDEX FOR TOOL NUMBER

A	2
B	2
C	3
D	4
E	5
F	5
G	5
H	6
I	6
J	7
K	7
L	7
M	7
N	8
O	9
P	9
Q	9
R	9
S	9
T	11
V	12
W	13
X	14
Z	14



INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
A					
AD-BM10	Banjo adapter	F236	APX4KUR0000WA00000A	APX4000 type end mill	L120
AD-G1/8	Adapter	F236	APX4KUR0209A16A	APX4000 type end mill	L120
AEMW00000000ER	Insert (For BAE type end mill)	K030,K031	APX4KUR2516CA22A	APX4000 type end mill	L120
AHX440S0000000R	AHX440S type face mill (Metric type)	L040	AQXR000M00A00	AQX type screw-in end mill (Metric type)	L199
AHX440SR0000000	AHX440S type face mill (Metric type)	L039	AQXR000SA/SN00S/L	AQX type end mill (Metric type)	L197,L198
AHX440SUR0000000	AHX440S type face mill	L038	AQXUR000SA/WA00S/L	AQX type end mill	L196
AHX475S0000000R	AHX475S type face mill (Metric type)	L045	ARP0PR000000A	ARP type face mill (Metric type)	L238
AHX475SR0000000	AHX475S type face mill (Metric type)	L045	ARP00UPR0000FA/SA00ML	ARP type end mill	L237
AHX475SUR0000000	AHX475S type face mill	L044	ARP0PR0000SA00ML	ARP type end mill (Metric type)	L240
AHX640S0000000R	AHX640S type face mill (Metric type)	L051	ARP0P000A00AR	ARP type face mill (Metric type)	L239
AHX640SR0000000	AHX640S type face mill (Metric type)	L050	ARP0UPR00000A	ARP type face mill	L236
AHX440SUR/L0000000	AHX640S type face mill	L048,L049	ARP0UPR0000AM0000	ARP type screw-in end mill	L241
AHX640W0000000R/L	AHX640W type face mill	L063	ARP0PR0000AM0000	ARP type screw-in end mill (Metric type)	L242
AHX640WR/L0000000	AHX640W type face mill	L060,L061	ARX00R000M00A00	ARX type screw-in end mill (Metric type)	L249
AHX640WR/L0000000	AHX640W type face mill (Metric type)	L062	ARX00R000SA00LW	ARX type end mill (Metric type)	L249
AJS0000T00	Clamp screw (For AJX type cutter)	N003	ARX00R000SA00S	ARX type end mill (Metric type)	L248
AJX00000A/B00R	AJX type face mill (Metric type)	L212	ASX40000000R	ASX400 type face mill (Metric type)	L084
AJX00R0000000	AJX type face mill (Metric type)	L212	ASX400R00000	ASX400 type face mill	L082
AJX00R000AM0000	AJX type screw-in end mill (Metric type)	L214	ASX400R00000C/D/E/F/K	ASX400 type face mill (Metric type)	L083
AJX00R000SA00S/SS/L/EL	AJX type end mill (Metric type)	L210,L211	ASX400R00000C/E/M	ASX400 type face mill	L082
AJX14RA00000E/F	AJX type cutter	L207	ASX400R000AM1600	ASX400 type screw-in end mill (Metric type)	L083
AJXU00R0000	AJX type face mill	L207	ASX400R000S32	ASX400 type end mill (Metric type)	L084
AJXU00R000AM0000	AJX type screw-in end mill	L209	ASX400R000W20	ASX400 type end mill	L085
AJXU00R0000C/E	AJX type face mill	L207	ASX445000000R	ASX445 type face mill (Metric type)	L032
AJXU00R000FA/SAWA00SIML	AJX type end mill	L206	ASX445R0000	ASX445 type face mill	L030
AMS0	Clamp bridge (For AJX/BRE type cutter)	N015	ASX445R0000C/E/M	ASX445 type face mill	L030,L031
AOGT123600PEFR-GM	Insert (For APX3000 type cutter)	K026,L103	ASX445R000S32	ASX445 type end mill	L031
AOMT123600PEER-H/M	Insert (For APX3000 type cutter)	K026,L103	AXD40000000A00R0	AXD4000 type face mill (Metric type)	L160
AOMT184800PEER-H/M	Insert (For APX4000 type cutter)	K026,L116	AXD4000R000000A/B	AXD4000 type face mill (Metric type)	L159
AOX445063A04R	AOX445 type face mill (Metric type)	L069	AXD4000R000SA0000	AXD4000 type end mill (Metric type)	L158
AOX445R0000000	AOX445 type face mill (Metric type)	L069	AXD4000UR00000A/B	AXD4000 type face mill	L157
AOX445R000S32	AOX445 type end mill (Metric type)	L069	AXD4000UR0000SA000A/B	AXD4000 type end mill	L156
APGT0000PDRF-G0	Insert (For BAP300/400 type cutter)	K031	AXD70000000A/B00R0	AXD7000 type face mill (Metric type)	L168
APMT0000PDER-H0	Insert (For BAP300/400/SRM2 type cutter)	K031,L280,L281,L287	AXD7000R0000000	AXD7000 type face mill (Metric type)	L167
APMT0000PDER-M0	Insert (For BAP300/400/SRM2 type cutter)	K031,L280,L281,L287	AXD7000R00000A-H63A	AXD7000 type HSK shank end mill (Metric type)	L168
APX3K00000000000RA	APX3000 type end mill (Long cutting edge) (Metric type)	L107	AXD7000R0000SA00S0	AXD7000 type end mill (Metric type)	L167
APX3KR0000S000000A	APX3000 type end mill (Long cutting edge) (Metric type)	L107	AXD7000UR0000000	AXD7000 type face mill	L166
APX3KUR2.0004AA18A20	APX3000 type end mill (Long cutting edge)	L106	AXD7000UR000SA00S0	AXD7000 type end mill	L166
APX3KUR000FA/FN00S00A00	APX3000 type end mill (Long cutting edge)	L106	B		
APX3000000A00RA	APX3000 type face mill (Metric type)	L100	BB-G1/8	Banjo bolt	F236
APX3000R00000CA/DA	APX3000 type face mill (Metric type)	L101	BC5	Clamp set (For F type boring bar)	N003
APX3000R00000A/B	APX3000 type face mill	L098	BGP141	Shim pin	N014
APX3000R000M00A00	APX3000 type screw-in end mill (Metric type)	L102	BF-CCGT0000002	Insert (Class G tolerance)	B045
APX3000UR000AM00A00	APX3000 type screw-in end mill	L102	BF-CCGW000TS2	Insert (Class G tolerance)	B045
APX3000R000SA000A	APX3000 type end mill (Metric type)	L099	BF-CNGG000TA4	Insert (Class G tolerance)	B028
APX3000UR000SA/FA0000	APX3000 type end mill	L096,L097	BF-CNGM000002	Insert (Class G tolerance)	B030
APX4000000A00RA	APX4000 type face mill (Metric type)	L114	BF-DCGT0000002	Insert (Class G tolerance)	B049
APX4000R000000A	APX4000 type face mill (Metric type)	L113	BF-DNGG000TA4	Insert (Class G tolerance)	B032
APX4000R000M00A00	APX4000 type screw-in end mill (Metric type)	L115	BF-DNGM000002	Insert (Class G tolerance)	B034
APX4000R000SA000A	APX4000 type end mill (Metric type)	L112	BLS00	Clamp screw	N003
APX4000UR0000000	APX4000 type face mill	L111	BM-CCGT000TA2	Insert (Class G tolerance)	B045
APX4000UR000AM00A00	APX4000 type screw-in end mill	L115	BM-CNGM000TA2	Insert (Class G tolerance)	B030
APX4000UR000SA/FA0000	APX4000 type end mill	L110	BM-DCGT000TA2	Insert (Class G tolerance)	B049
APX4K00000A0000RA	APX4000 type end mill (Metric type)	L121	BM-DNGM000TA2	Insert (Class G tolerance)	B034
APX4KR00000CA00000A	APX4000 type end mill (Metric type)	L121	BMR	BMR bore boring cutter	L292
APX4KR06316CA056A	APX4000 type end mill (Metric type)	L121	BM-TNGM000TA3	Insert (Class G tolerance)	B037

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
BOER○○○○A/C/E/F	BOE type face mill	L257	CCGT○○○FJ	Insert (Class G tolerance)	A147
BOER○○○W20	BOE type end mill	L256	CCGT○○○FJ-P	Insert (Class G tolerance)	A148
BRP○○○R○○○ELSO○	BRP type end mill	L252	CCGT○○○MFS	Insert (Class G tolerance)	A147
BRP○○○R○○○ELW○○	BRP type end mill	L252	CCGT○○○MFS-P	Insert (Class G tolerance)	A147
BRP○○○R○○○LW○○	BRP type end mill	L252	CCGT○○○MJ	Insert (Class G tolerance)	A151
BRP○○○R○○○W○○	BRP type end mill	L252	CCGT○○○MJ-P	Insert (Class G tolerance)	A151
BRP○UPR○○○○	BRP type face mill	L253	CCGT○○○MLS	Insert (Class G tolerance)	A150
BRP○UPR○○○○C/E/X	BRP type face mill	L253	CCGT○○○MLS-P	Insert (Class G tolerance)	A151
BRS105	Clamp screw (For BRE type end mill)	N003	CCGT○○○○○○MR/L-F	Insert (Class G tolerance)	A148,A149
BTAHR/L-○○○	External back turning holder	D016	CCGT○○○MR/LSS	Insert (Class G tolerance)	A150
BTAHR/L○○○○-50	External back turning holder	D019	CCGT○○○MR/LSN	Insert (Class G tolerance)	A154
BTAT○○○○○○R/L-B	External back turning insert	D016,D019	CCGT○○○MSG	Insert (Class G tolerance)	A155
BTAT603501MR-B	Insert for external back turning	D016,D019	CCGT○○○R/LSN	Insert (Class G tolerance)	A154
BTAT605000RX	External back turning insert	D016,D019	CCGT○○○R/LSS	Insert (Class G tolerance)	A150
BTAT72350○MR-SMB	Insert for external back turning	D016,D019	CCGW○○○	Insert (Class G tolerance)	A155,B046
BTAT7235V5R-SMB	Insert for external back turning	D016,D019	CCGW○○○E	Insert (Class G tolerance)	A155
BTBT○○○○○○MR-B	Insert for external back turning	D017,D020	CCGW○○○V○	Insert (Class G tolerance)	A155
BTBT○○○○○○R/L-B	External back turning insert	D017,D020	CCGW○○○FS	Insert (Class G tolerance)	B046
BTBT606000R/L	External back turning insert	D017,D020	CCMH○○○MV	Insert (Class M tolerance)	A152
BTBT7055○MR-SMB	Insert for external back turning	D017,D020	CCMH○○○SV	Insert (Class M tolerance)	A149
BTBT7055V5R-SMB	Insert for external back turning	D017,D020	CCMT○○○	Insert (Class M tolerance)	A152
BTVHR-○○○	External back turning holder	D018	CCMT○○○FM	Insert (Class M tolerance)	A147
BTVHR○○○○-75	External back turning holder	D021	CCMT○○○FP	Insert (Class M tolerance)	A147
BTVHR○○○○-75F	External back turning holder	D021	CCMT○○○FV	Insert (Class M tolerance)	A147
BTVT○○○○○○R-B	External back turning insert	D018,D021	CCMT○○○LM	Insert (Class M tolerance)	A149
BXD4000-○○○A/B○○RA/RB	BXD4000 type face mill (Metric type)	L178	CCMT○○○LP	Insert (Class M tolerance)	A149
BXD4000R○○○○	BXD4000 type face mill	L177	CCMT○○○LS	Insert (Class M tolerance)	A149
BXD4000R○○○○○○○	BXD4000 type face mill (Metric type)	L178	CCMT○○○MK	Insert (Class M tolerance)	A152
BXD4000R○○○○○B	BXD4000 type face mill	L177	CCMT○○○MM	Insert (Class M tolerance)	A151
BXD4000R○○○○SA○○○○	BXD4000 type end mill (Metric type)	L179	CCMT○○○MP	Insert (Class M tolerance)	A151
BXD4000R○○○○SA○○S/SB	BXD4000 type end mill	L176	CCMT○○○MS	Insert (Class M tolerance)	A151
C			CCMT○○○MW	Insert (Class M tolerance)	A152
C○○○R-BLS	MICRO-MINI boring bar	E031	CCMT○○○SW	Insert (Class M tolerance)	A149
C○○○SCLCR○○	MICRO-DEX holder (Carbide shank)	E029	CCMW○○○	Insert (Class M tolerance)	A155,B063
C○○○SWUBR○○	MICRO-DEX holder (Carbide shank)	E029	CCMX○○○○○○ENA/B	Insert (For LER type end mill)	K035,L194
C○-GYHR/L○90-M25R/L	GY type holder (External 90° type)	F196-F205	CE4SRB	Ceramic end mill (Metric type)	I280
C○-GYHR/L○X00-M○○R/L	GY type holder (External 00° type)	F186-F195	CE6SRB	Ceramic end mill (Metric type)	I281
C07KSTUCR06	MICRO-DEX holder (Carbide shank)	E030	CFC/FM○○○○○	Clamp screw	N002
C2MHA	Uncoated carbide end mill (Metric type)	I282	CFSPR○○○W○○	CFSP type end mill	L260
C3-GYHR/LCX90-M20R/L	GY type holder (External 90° type)	F196-F205	CG○○RS-○○	MICRO-MINI TWIN (For Grooving)	F241
C4LATB	Uncoated carbide end mill (Metric type)	I284	CG○○○○RS-○○	MICRO-MINI TWIN (For Grooving)	F241
C6-GYHR/LF00-M25R/L	GY type holder (External 00° type)	F186-F195	CG○○RS-○OB	MICRO-MINI TWIN (For Grooving)	F241
CAS51T	Clamp screw (For BF407 type face mill)	N003	CG○○○○RS-○OB	MICRO-MINI TWIN (For Grooving)	F241
CB○○RS	MICRO-MINI TWIN boring bar	E032	CLO	Clamp bridge	N015
CB○○RS-B	MICRO-MINI TWIN boring bar	E032	CLO○	Clamp bridge	N015
CBC4	Chipbreaker	N016	CNG○○○	Insert (Class G tolerance)	B041
CBH○○○○○	Clamp screw	N002	CNGA○○○	CBN insert (Class G tolerance)	B030
CBN2XLB	CBN end mill (Metric type)	I276	CNGG○○○FJ	Insert (Class G tolerance)	A104
CBN2XLRB	CBN end mill (Metric type)	I278	CNGG○○○○FJ-P	Insert (Class G tolerance)	A104
CBR4	Chipbreaker	N016	CNGG○○○MJ	Insert (Class G tolerance)	A106
CBS○	Chipbreaker	N016	CNGG○○○PK	Insert (Class G tolerance)	A105
CBS○D	Chipbreaker	N016	CNMA○○○	Insert (Class M tolerance)	A111,B059
CBT3	Chipbreaker	N016	CNMG○○○	Insert (Class M tolerance)	A108
CCET○○○R/LSN	Insert (Class E tolerance)	A153	CNMG○○○C	Insert (Class M tolerance)	A106
CCET○○○R/LSR	Insert (Class E tolerance)	A153	CNMG○○○FP	Insert (Class M tolerance)	A104
CCET○○○R/LWSN	Insert (Class E tolerance)	A154	CNMG○○○FH	Insert (Class M tolerance)	A104
CCGH○○○R/LF	Insert (Class G tolerance)	A149	CNMG○○○FS	Insert (Class M tolerance)	A104
CCGH○○○○○○MR/L-F	Insert (Class G tolerance)	A149	CNMG○○○FY	Insert (Class M tolerance)	A104
CCGT○○○○○○L-F	Insert (Class G tolerance)	A148	CNMG○○○GH	Insert (Class M tolerance)	A110
CCGT○○○AZ	Insert (Class G tolerance)	A148	CNMG○○○GJ	Insert (Class M tolerance)	A110
			CNMG○○○GK	Insert (Class M tolerance)	A107
			CNMG○○○GM	Insert (Class M tolerance)	A107

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
CNMG○○○LK	Insert (Class M tolerance)	A105	C-SWL0502R/LS	Screw clamp type boring bar (Carbide shank)...	E017
CNMG○○○LM	Insert (Class M tolerance)	A105	C-SWL0504R/L	Screw clamp type boring bar (Carbide shank)...	E017
CNMG○○○LP	Insert (Class M tolerance)	A105	C-SWL05S3R/LM	Screw clamp type boring bar (Carbide shank)...	E017
CNMG○○○LS	Insert (Class M tolerance)	A105	CT○○RS-M○	MICRO-MINI TWIN boring bar	G034
CNMG○○○MA	Insert (Class M tolerance)	A107	CT○○RS-M○○	MICRO-MINI TWIN boring bar	G034
CNMG○○○MH	Insert (Class M tolerance)	A108	CT○○RS-M○○B	MICRO-MINI TWIN boring bar	G034
CNMG○○○MJ	Insert (Class M tolerance)	A106	CT○○RS-M○B	MICRO-MINI TWIN boring bar	G034
CNMG○○○MK	Insert (Class M tolerance)	A107	CTAHR/L-○○○	External cutting off holder	D026
CNMG○○○MM	Insert (Class M tolerance)	A107	CTAHR/L○○○○-120	External cutting off holder	D028
CNMG○○○MP	Insert (Class M tolerance)	A106	CTAHR1010-120S	External cutting off holder	D028
CNMG○○○MS	Insert (Class M tolerance)	A108,A109	CTAHR-○○○S	External cutting off holder	D026
CNMG○○○MW	Insert (Class M tolerance)	A108	CTAT○○○○○○○R/L○	External cutting off insert	D027,D029
CNMG○○○RK	Insert (Class M tolerance)	A109	CTAT○○○○○○○R/L○-B	External cutting off insert	D027,D029
CNMG○○○RM	Insert (Class M tolerance)	A109	CTAT○○○○○○○R○-BX	External cutting off insert	D027,D029
CNMG○○○RP	Insert (Class M tolerance)	A109	CTBHR/L-○○○	External back turning, cutting off holder	D017,D030
CNMG○○○RS	Insert (Class M tolerance)	A110	CTBHR/L○○○○-160	External back turning, cutting off holder	D020,D031
CNMG○○○SA	Insert (Class M tolerance)	A105	CTBT○○○○○○○R/L○-B	External cutting off insert	D030,D031
CNMG○○○SH	Insert (Class M tolerance)	A105	CTCHR/L○○○○-200	External cutting off holder	D032
CNMG○○○SW	Insert (Class M tolerance)	A105	CTCT○○○○○○○-B	External cutting off insert	D032
CNMG○○○SY	Insert (Class M tolerance)	A106	CTDHR/L○○○○-○○○	External cutting off holder	D033
CNMM○○○HL	Insert (Class M tolerance)	A111	CTDT○○○○○○○-B	External cutting off insert	D033
CNMM○○○HM	Insert (Class M tolerance)	A111	CTDT○○○○○○○-BS	External cutting off insert	D033
CNMM○○○HR	Insert (Class M tolerance)	A111	CTE○○T○○○	Shim	G021,N013
CNMM○○○HV	Insert (Class M tolerance)	A111	CTEHR/L○○○○-○○○	External cutting off holder	D034
CNMM○○○HX	Insert (Class M tolerance)	A111	CTET○○○○○○○-B	External cutting off insert	D034
CNMM○○○HZ	Insert (Class M tolerance)	A110	CTET○○○○○○○-BS	External cutting off insert	D034
CNMN○○○	Insert (Class M tolerance)	A144	CTI○○T○○○	Shim	G026,N013
CNMP○○○	Insert (Class M tolerance)	A109	D		
CPGT○○○	Insert (Class G tolerance)	A156,B063			
CPGT○○○R/LF	Insert (Class G tolerance)	A156	DC2SB	Diamond coated end mill (Metric type)	I272
CPM○○○○○	Clamp screw	N002	DC2XLB	Diamond coated end mill (Metric type)	I274
CPMH○○○FV	Insert (Class M tolerance)	A156	DC○○○○T	Clamp screw	N003
CPMH○○○MV	Insert (Class M tolerance)	A157	DCET○○○R/LSN	Insert (Class E tolerance)	A163
CPMH○○○R/LF	Insert (Class M tolerance)	A156	DCET○○○R/LSR	Insert (Class E tolerance)	A163
CPMH○○○SV	Insert (Class M tolerance)	A156	DCET○○○R/LWSN	Insert (Class E tolerance)	A164
CPMT○○○MQ	Insert (Class M tolerance)	A157	DCGT○○○AZ	Insert (Class G tolerance)	A159
CPMT○○○SQ	Insert (Class M tolerance)	A156	DCGT○○○FJ	Insert (Class G tolerance)	A158
CPMT1205ZPEN-M○	Insert (For PMR type end mill)	K037,L291	DCGT○○○FJ-P	Insert (Class G tolerance)	A158
CPMX○○○	Insert (Class M tolerance)	A157	DCGT○○○MFS	Insert (Class G tolerance)	A158
CR○	Stop ring (For SRE type end mill)	N014	DCGT○○○MFS-P	Insert (Class G tolerance)	A159
CR○○RS-○○	MICRO-MINI TWIN boring bar	E033	DCGT○○○MJ	Insert (Class G tolerance)	A161
CR○○RS-○○B	MICRO-MINI TWIN boring bar	E033	DCGT○○○MJ-P	Insert (Class G tolerance)	A161
CS○○○○○T	Clamp screw	N003	DCGT○○○MLS	Insert (Class G tolerance)	A161
CS○○○○○TS	Clamp screw	N003	DCGT○○○MLS-P	Insert (Class G tolerance)	A161
CS-1/8-○○○○○	Coolant hose kit	F236	DCGT○○○MR/LSN	Insert (Class G tolerance)	A164
CSC/SD/SP/SR/SS○○○○○	Clamp screw	N002	DCGT○○○MR/LSS	Insert (Class G tolerance)	A160
C-SCLCR/L-○○○	Screw clamp type boring bar (Carbide shank)...	E013	DCGT○○○MSMG	Insert (Class G tolerance)	A165
C-SDQCR/L-○○○	Screw clamp type boring bar (Carbide shank)...	E014	DCGT○○○R/LF	Insert (Class G tolerance)	A159
C-STUCR/L-○○○	Screw clamp type boring bar (Carbide shank)...	E016	DCGT○○○R/LSN	Insert (Class G tolerance)	A164
CSVHR/L-○○○	External turning holder	D041	DCGT○○○R/LSS	Insert (Class G tolerance)	A160
CSVHR/L○○○○	External turning holder	D044	DCGW○○○	Insert (Class G tolerance)	A165,B049
CSVTB○○○R/L	External back turning insert	D042,D045	DCGW○○○FS	Insert (Class G tolerance)	B049
CSVTB○○○R-B	External back turning insert	D042,D045	DCK○○○○	Clamp bridge	N015
CSVTBXL	External back turning copying insert	D042,D045	DCLNR/L-○○○	Double clamp type holder	C006
CSVTC○○○○R/L	External cutting off insert	D042,D045	DCMT○○○	Insert (Class M tolerance)	A162
CSVTC○○○○R-B	External cutting off insert	D042,D045	DCMT○○○FM	Insert (Class M tolerance)	A158
CSVTF○○○R/L	External front turning insert	D041,D044	DCMT○○○FP	Insert (Class M tolerance)	A158
CSVTF○○○R/L-B	External front turning insert	D041,D044	DCMT○○○FV	Insert (Class M tolerance)	A158
CSVTFXL	External front turning copying insert	D041,D044	DCMT○○○LM	Insert (Class M tolerance)	A159
CSVTG○○○○○R/L	External grooving insert	D043,D046	DCMT○○○LP	Insert (Class M tolerance)	A159
CSVTT60050RR/L	External threading insert	D043,D046	DCMT○○○LS	Insert (Class M tolerance)	A160
C-SWLOR/L-○○○	Screw clamp type boring bar (Carbide shank)...	E019			

ORDER NUMBER	PRODUCT NAME	PAGE
DCMT000MS	Insert (Class M tolerance)	A162
DCMT000MK	Insert (Class M tolerance)	A161
DCMT000MM	Insert (Class M tolerance)	A161
DCMT000MP	Insert (Class M tolerance)	A161
DCMT000MV	Insert (Class M tolerance)	A162
DCMT000SV	Insert (Class M tolerance)	A160
DCMW000	Insert (Class M tolerance)	A165,B064
DCRNR/L-000	Double clamp type holder	C008
DCS0	Spring	C006—C027,N014
DCSVN32	Shim	N010
DDJNR/L-000	Double clamp type holder	C010
DDPNN-164	Double clamp type holder	C011
DDQNR/L-164	Double clamp type holder	C012
DEGX000R/L	Insert (Class G tolerance)	A166
DEGX000R/LF	Insert (Class G tolerance)	A166,B070
DF2MB	Diamond coated end mill (Metric type)	I258
DF2XLB	Diamond coated end mill (Metric type)	I260
DF2XLBF	Diamond coated end mill (Metric type)	I264
DF3XB	Diamond coated end mill (Metric type)	I266
DF4JC	Diamond coated end mill (Metric type)	I254
DF4XL	Diamond coated end mill (Metric type)	I255
DFC4JC	DFC end mill (Metric type)	I252
DFCJRT	DFC end mill (Metric type)	I253
DFPSRB	Diamond coated end mill (Metric type)	I268
DLE0000CS000P000	Leading drills	M172
DNG000	Insert (Class G tolerance)	B041
DNGA000	Insert (Class G tolerance)	A118,B059
DNGG000FJ	Insert (Class G tolerance)	A112
DNGG000PK	Insert (Class G tolerance)	A113
DNGG000R/L	Insert (Class G tolerance)	A117
DNGM000MJ	Insert (Class G tolerance)	A115
DNMA000	Insert (Class M tolerance)	A118
DNMG000	Insert (Class M tolerance)	A116
DNMG000C	Insert (Class M tolerance)	A114
DNMG000FP	Insert (Class M tolerance)	A112
DNMG000FH	Insert (Class M tolerance)	A112
DNMG000FS	Insert (Class M tolerance)	A112
DNMG000FY	Insert (Class M tolerance)	A112
DNMG000GH	Insert (Class M tolerance)	A118
DNMG000GJ	Insert (Class M tolerance)	A118
DNMG000GK	Insert (Class M tolerance)	A115
DNMG000GM	Insert (Class M tolerance)	A115
DNMG000LK	Insert (Class M tolerance)	A113
DNMG000LM	Insert (Class M tolerance)	A113
DNMG000LP	Insert (Class M tolerance)	A113
DNMG000LS	Insert (Class M tolerance)	A113
DNMG000MA	Insert (Class M tolerance)	A116
DNMG000MH	Insert (Class M tolerance)	A116
DNMG000MJ	Insert (Class M tolerance)	A114
DNMG000MK	Insert (Class M tolerance)	A115
DNMG000MM	Insert (Class M tolerance)	A115
DNMG000MP	Insert (Class M tolerance)	A115
DNMG000MS	Insert (Class M tolerance)	A117
DNMG000RK	Insert (Class M tolerance)	A117
DNMG000RM	Insert (Class M tolerance)	A117
DNMG000RP	Insert (Class M tolerance)	A117
DNMG000RS	Insert (Class M tolerance)	A117
DNMG000SA	Insert (Class M tolerance)	A114
DNMG000SH	Insert (Class M tolerance)	A113
DNMG000SY	Insert (Class M tolerance)	A114
DNMM000HL	Insert (Class M tolerance)	A118
DNMM000HZ	Insert (Class M tolerance)	A118

ORDER NUMBER	PRODUCT NAME	PAGE
DNMX000MW	Insert (Class M tolerance)	A116
DNMX000SW	Insert (Class M tolerance)	A114
DRGNR/L-000	Double clamp type holder	C013
DSAE0000XC000S000	DSAE type drill (Metric type)	M158—M160
DSAS0000XC000S000	DSAS type drill (Metric type)	M158—M160
DSDNN-000	Double clamp type holder	C016
DSKNR/L-000	Double clamp type holder	C017
DSRRNR/L-000	Double clamp type holder	C014
DSSNR/L-000	Double clamp type holder	C015
DTCNN-000	Double clamp type holder	C022
DTFNR/L-000	Double clamp type holder	C022
DTGNR/L-000	Double clamp type holder	C018
DVJNR/L-000	Double clamp type holder	C024
DVPNR/L-000	Double clamp type holder	C025
DVVNN-000	Double clamp type holder	C025
DWLNRL/L-000	Double clamp type holder	C027

E

E000-SCLCR/L0	Coolant through carbide	E040
E000-SCLPR/L0	Coolant through carbide	E041
E000-SDQCR/L0	Coolant through carbide	E042
E000-SDUCR/L0	Coolant through carbide	E043
E000-STUCR/L0	Coolant through carbide	E044
E000-STUPR/L0	Coolant through carbide	E045
E000-SVUCR/L0	Coolant through carbide	E046
E000-SWLOR/L0	Coolant through carbide	E047

F

FC400890T	Clamp screw (For AL type boring bar)	N003
FMAX-000A00R	FMAX type face mill (Metric type)	L071
FMAXR0000000	FMAX type face mill (Metric type)	L072,L073
FMAXUR000000	FMAX type face mill	L070
FSL5000R	Grooving and threading boring bar	F238,G031
FSWL000RS/RM	Screw clamp boring bar	E018
FSWL000R/LM	Screw clamp boring bar	E018
FSWL1000R	Screw clamp boring bar	E018
FSWL200R	Screw clamp boring bar	E018

G

GOER0000PXFR2	Insert (For FMAX type cutter)	K051,L074
GOER1401ZXFR2	Insert (For FMAX type cutter)	K051,L074
GOER1408PXFR2-8	Insert (For FMAX type cutter)	K051,L074
GTBHR/L-000	External grooving holder	D022
GT0HR/L0000-00	External grooving holder	D024
GT0HR/L0000-00S	External grooving holder	D024
GT0T00000000R-VT	External grooving insert	D023,D025
GT0T00000000R/L-E	External grooving insert	D023,D025
GT0T00000000R/L-U	External grooving insert	D022,D024
GTS0	Clamp screw	N004
GW1B0000000000N	Inserts (For GW blade)	F235
GW1M0000000000N-00	Inserts (For GW blade)	F235
GW1M0000000000R/L05-GM	Inserts (For GW blade)	F235
GW04005F	Plug screw (For GW blade)	F232
GWB00NA2-000	GW blade (For GW blade)	F232
GWCW0	Wedge (For GW blade)	F233,F234
GWTBN0000-B00	Tool block (For GW blade)	F234
GWTBNUS00-B00	Tool block (For GW blade)	F233
GWTBN0000-B00-C	Tool block (For GW blade)	F234
GWTBNUS00-B00-C	Tool block (For GW blade)	F233

6

ORDER NUMBER	PRODUCT NAME	PAGE
GWW○○○○○	Washer (For GW blade)	F232
GWY39L.....	Wrench (For GW blade)	F232
GY○○○○S/M.....	Clamp screw.....	F040—F205,N004
GY●B○○○○○○○N.....	Insert (For GY holder).....	F015
GY1G○○○○○○○N-GFGS...	CBN Insert (For GY holder).....	B058,F012
GY2G○○○○○○○N-○○.....	Insert (For GY holder).....	F012,F013
GY●M○○○○○○○N-○○.....	Insert (For GY holder).....	F011—F014
GY●M○○○○○○○R/L05-GM.....	Insert (For GY holder).....	F012
GYAR/L○○○90○-○○○.....	GY type holder (Internal 90° type) ...	F178—F185
GYAR/LUS○○○90○-○○○.....	GY type holder (Internal 90° type) ...	F170—F177
GYDR/L○○○90○-M○○R/L.....	GY type holder (Internal 90° type) ...	F178—F185
GYDR/LUS○○○90○-M○○R/L.....	GY type holder (Internal 90° type) ...	F170—F177
GYHR/L○○○○○00-M○○R/L.....	GY type holder (External 00° type).....	F064—F075,F128—F159
GYHR/L○○○○○50-M○○R/L.....	GY type holder (External 50° type).....	F084
GYHR/L○○○○○90-M○○R/L.....	GY type holder (External 90° type).....	F078—F083,F160—F169
GYHR/LUS○○○00-M○○R/L.....	GY type holder (External 00° type).....	F040—F051,F086—F117
GYHR/LUS○○○50-M○○R/L.....	GY type holder (External 50° type).....	F060
GYHR/LUS○○○90-M○○R/L.....	GY type holder (External 90° type).....	F054—F059,F118—F127
GYM○○R/L○-○○○.....	Modular Blade (For GY holder)	F040—F205
GYPR/L○○○○○00-K25.....	GY type holder (External 00° type).....	F076
GYPR/LUS○○○D00-K25.....	GY type holder (External 00° type).....	F052
GYQR/L○○○○○00-○○○.....	GY type holder (External 00° type).....	F064,F068—F075
GYQR/LUS○○○00-○○○.....	GY type holder (External 00° type)...F040—F051	
GYSR/L○○○○JX00-○○○.....	GY type holder (External 00° type).....	F062
GYSR/LUS○○○B00-○○○.....	GY type holder (External 00° type).....	F038
H		
H100TH-B○○-○○○.....	HSK boring bar holder.....	H022
H100TH-EN3232R/L-130.....	HSK external turning tool holder.....	H020
H100TH-EV3232R/L-180.....	HSK external turning tool holder.....	H019
H63TH-A○○○DCLNR/L12.....	HSK DCLN type holder.....	H008
H63TH-B○○-○○○.....	HSK boring bar holder.....	H021
H63TH-DCLNL-L12-3.....	HSK DCLN type holder.....	H008
H63TH-DCLNR/L-DX12.....	HSK DCLN type holder.....	H006
H63TH-DCMNN-H/L12.....	HSK DCMN type holder.....	H007
H63TH-DDJNL-L15-3.....	HSK DDJN type holder.....	H011
H63TH-DDJNR/L-DX15.....	HSK DDJN type holder.....	H009
H63TH-DDNNN-H/L15.....	HSK DDNN type holder.....	H010
H63TH-EN2525R/L-115.....	HSK external turning tool holder.....	H020
H63TH-EV2020R/L-105-3.....	HSK external turning tool holder.....	H021
H63TH-EV2525R/L-112.....	HSK external turning tool holder.....	H019
H63TH-MGHR/L-DX43○○.....	HSK MG type holder.....	H014
H63TH-MMTENR-H/L16.....	HSK MMT type holder.....	H016
H63TH-MMTer-DX16.....	HSK MMT type holder.....	H016
H63TH-MTHR/L-DX43.....	HSK MT type holder.....	H017
H63TH-PCLNR/L-DX12.....	HSK PCLN type holder.....	H006
H63TH-PCMNN-H/L12.....	HSK PCMN type holder.....	H007
H63TH-PDJNR/L-DX15.....	HSK PDJN type holder.....	H009
H63TH-PDNNN-H/L15.....	HSK PDNN type holder.....	H010
H63TH-PRDCN-H/L12.....	HSK PRDC type holder.....	H012
H63TH-PRGCR/L-DX12.....	HSK PRGC type holder.....	H012
H63TH-SVPBR/L-DX16.....	HSK SVPB type holder.....	H013
H63TH-SVVBN-H/L16.....	HSK SVVB type holder.....	H013
HBH○○○○○.....	Clamp screw.....	N002,N008
HDS10031.....	Clamp screw.....	N008
HDSU37513.....	Clamp screw.....	N008
I		
ICSN○○○.....	Shim	N010
IDSN○○○.....	Shim	N010
IMX○○-○○○○○○○○○○○○○○L○○C.....	Exchangeable head end mill (Holder) (Inch type) ...	J070
IMX○○-○○○○○○○○○○○○○○L○○OC.....	Exchangeable head end mill (Holder) (Metric type) ...	J071
IMX○○-○○○○○○○○○○○○○○L○○OS.....	Exchangeable head end mill (Holder) (Inch type) ...	J072
IMX○○-○○○○○○○○○○○○○○L○○S.....	Exchangeable head end mill (Holder) (Metric type) ...	J073
IMX○○-○○○○○○○○○○○○○○L○○S.....	Exchangeable head end mill (Holder) (Inch type) ...	J072
IMX○○-G○○L○○OS.....	Exchangeable head end mill (Holder) (Metric type) ...	J073
IMX-○○HV.....	Exchangeable head end mill (Head) (Inch type) ...	J006,J010,J030,J036,J038,J050
IMX-○○HV.....	Exchangeable head end mill (Head) (Metric type) ...	J006,J011,J031,J036,J039,J051
IMX○○-S○○L○○OC.....	Exchangeable head end mill (Holder) (Metric type) ...	J071
IMX-○3A.....	Exchangeable head end mill (Head) (Inch type) ...	J018,J058
IMX-○3A.....	Exchangeable head end mill (Head) (Metric type) ...	J019,J059
IMX-○4HV-○.....	Exchangeable head end mill (Head) (Inch type) ...	J012,J032,J042
IMX-○4HV-○.....	Exchangeable head end mill (Head) (Metric type) ...	J012,J033,J043
IMX-B2S.....	Exchangeable head end mill (Head) (Metric type) ...	J026
IMX-B3FV.....	Exchangeable head end mill (Head) (Metric type) ...	J028
IMX-B4S.....	Exchangeable head end mill (Head) (Metric type) ...	J027
IMX-C○○HV.....	Exchangeable head end mill (Head) (Inch type) ...	J050
IMX-C○○HV.....	Exchangeable head end mill (Head) (Metric type) ...	J051
IMX-COT-C.....	Exchangeable head end mill (Head) (Metric type) ...	J062
IMX-COOT-C.....	Exchangeable head end mill (Head) (Metric type) ...	J062
IMX-C4FD-C.....	Exchangeable head end mill (Head) (Inch type) ...	J053
IMX-C4FD-C.....	Exchangeable head end mill (Head) (Metric type) ...	J054
IMX-C4FV.....	Exchangeable head end mill (Head) (Inch type) ...	J056
IMX-C4FV.....	Exchangeable head end mill (Head) (Metric type) ...	J056
IMX-CH3L.....	Exchangeable head end mill (Head) (Inch type) ...	J064
IMX-CH3L.....	Exchangeable head end mill (Head) (Metric type) ...	J065
IMX-CH6V.....	Exchangeable head end mill (Head) (Inch type) ...	J068

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
IMX-CH6V	Exchangeable head end mill (Head) (Metric type)...	J068	MBA	Clamp screw.....	N009
IMX-R4F	Exchangeable head end mill (Head) (Inch type)...	J022	MBAU100016H	Clamp screw (For AJX type cutter).....	N009
IMX-R4F	Exchangeable head end mill (Head) (Metric type)...	J023	MBAU75016H	Clamp screw (For AJX type cutter).....	N009
IRSN	Shim.....	N010	MCFNR/L-	Multiple clamp holder.....	C009
ISSN	Shim.....	N010	MCFNR/L-	Multiple clamp holder.....	C009
ITSN	Shim.....	N010	MCGNR/L-	Multiple clamp holder.....	C008
IVSN	Shim.....	N010	MCGNR/L-	Multiple clamp holder.....	C008
IWSN	Shim.....	N011	MCLNR/L-	Multiple clamp holder.....	C007
J			MCLNR/L-	Multiple clamp holder.....	C007
JDMT	Insert (For AJX type cutter).....	K025,L216	MCRNR/L-	Multiple clamp holder.....	C009
JDMT	Insert (For AJX/PMC type cutter)...	K025,L216,L289	MDJNR/L-	Multiple clamp holder.....	C010
JDMW	Insert (For AJX/PMC type cutter)...	K025,L216,L289	MDJNR/L-	Multiple clamp holder.....	C010
JFS	JUST FIT SLEEVE (JFS).....	M194	MDPNN-	Multiple clamp holder.....	C011
JFS	JUST FIT SLEEVE (JFS).....	M193	MES3	Spring.....	N014
JOMT	Insert (For AJX type cutter).....	K025,L216	MFE	MFE type drill.....	M162—M168
JOMT	Insert (For AJX type cutter).....	K025,L216,L289	M-FSCLCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E006
JOMU140715ZZER-	Insert (For WJX type cutter).....	K047,L231	M-FSCLPR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E006
JOMW	Insert (For AJX/PMC type cutter)...	K025,L216,L289	M-FSDQCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E008
JPMT060204-E	Insert (For milling).....	K049	M-FSDUCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E008
JPMX	Insert (For SPX type end mill).....	K039,L183	M-FSTUPR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E007
JPMX	Insert (For SPX type end mill).....	K039,L183	M-FSVJBR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E010
JSS	Shim screw.....	N004	M-FSVJCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E010
K			M-FSVPCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E010
KGC1	Clamp bridge (For UG tool block).....	N015	M-FSVUBR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E009
KNUX	Insert (Class U tolerance).....	A143	M-FSVUCR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E009
L			M-FSWUBR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E009
LER	LER type end mill.....	L194	M-FSWUPR/L-	Screw clamp DIMPLE BAR (Heavy metal shank)...	E009
LLCL	Clamp lever.....	N014	MGD	Driver (For MICRO-MGS type drill).....	M155
LLCL	Clamp lever.....	N014	MGS	MICRO-MGS type drill (Metric type).....	M154
LLCS	Clamp screw.....	N004	MGTR/L43	Insert (For grooving).....	H015
LLP	Shim pin.....	N014	MHS	MHS type drill (Metric type).....	M110—M125
LLSCN	Shim.....	N011	MK1KS	Anti seize lubricant.....	N017
LLSCP	Shim.....	N011	MLG	Insert (For FSL5 type boring bar).....	F240,G033
LLSDN	Shim.....	N011	MLG	Insert (For FSL5 type boring bar).....	F240,G033
LLSDP	Shim.....	N011	MLT	Insert (For FSL5 type boring bar).....	F240,G033
LLSRN123	Shim.....	N011	MMS	MMS type drill.....	M098—M107
LLSSN42	Shim.....	N011	MMS	MMS type drill.....	M098—M107
LLSSP42	Shim.....	N011	MMT	Insert (For external threading)...	G023,G024,G025
LLSTN	Shim.....	N011	MMT	Insert (For external threading).....	G022
LLSTP32	Shim.....	N011	MMT	Insert (For internal threading)...	G028,G029,G030
LLSWN	Shim.....	N011	MMT	Insert (For internal threading).....	G027
LLSWP42	Shim.....	N011	MMTER-	Threading holder.....	G021
LNGU1308	Insert (For VAS400 type side cutter)...	K043,L091	MMTER-	Threading holder.....	D038,G021
LNGU1710	Insert (For VAS500 type side cutter)...	K044,L093	MMTIR-	Threading holder.....	G026
LOGU	Insert (For VPX200/300 type cutter).....	K046,K047,L130,L147	M-MWLNRL/L-	Multiple clamp type boring bar (Heavy metal shank)...	E027
LS	Clamp screw.....	N004	MNS	MNS type drill (Metric type).....	M130—M134
LS	Clamp screw.....	N004	MNS	MNS type drill (Metric type).....	M130—M134
LS	Clamp screw.....	N004	MP2MB	MS PLUS end mill (Metric type).....	I096
LS0622T	Clamp screw.....	N004	MP2MB	MS PLUS end mill (Inch type).....	I099
M			MP2SB	MS PLUS end mill (Metric type).....	I095
MAE	MAE type drill (Metric type).....	M142—M146	MP2SDB	MS PLUS end mill (Metric type).....	I102
MAS	MAS type drill (Inch type).....	M140	MP2SSB	MS PLUS end mill (Metric type).....	I094
MAS	MAS type drill (Metric type).....	M142—M146	MP2XLB	MS PLUS end mill (Metric type).....	I104
			MP3MC	MS PLUS end mill (Inch type).....	I086
			MP4JC	MS PLUS end mill (Inch type).....	I090
			MP4MC	MS PLUS end mill (Inch type).....	I088
			MP4MRB	MS PLUS end mill (Inch type).....	I092
			MPMX120412-JM	Insert (For SPX type end mill).....	K039,L183
			MPMX120412-WH	Insert (For SPX type end mill).....	K039,L183
			MRGNR/L-	Multiple clamp type holder.....	C013
			MRGNR/L-	Multiple clamp type holder.....	C013

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
MS2ES	MSTAR end mill (Metric type).....	I072	MVX	MVX type drill (Inch type)	M176—M179
MS2JS	MSTAR end mill (Metric type).....	I038	MVX	MVX type drill (Metric type)	M181—M188
MS2LS	MSTAR end mill (Metric type).....	I040	MWLNRL/L	Multiple clamp type holder.....	C027
MS2MD	MSTAR end mill (Metric type).....	I036	MWS	MWS type drill	M082—M092
MS2MRB	MSTAR end mill (Metric type).....	I080	MWS	MWS type drill	M082—M092
MS2MS	MSTAR end mill (Metric type).....	I033	MWS	MWS type drill	M087—M092
MS2SS	MSTAR end mill (Metric type).....	I032	N		
MS2XL	MSTAR end mill (Metric type).....	I042	NKY	Driver wrench	N002
MS2XL	MSTAR end mill (Inch type).....	I050	NKY	Flag wrench	N002
MS2XL6	MSTAR end mill (Metric type).....	I046	NKY	Long L-wrench.....	N002
MS2XLB	MSTAR end mill (Inch type).....	I078	NKY	L-wrench.....	N002
MS3ES	MSTAR end mill (Metric type).....	I074	NKY	T-wrench.....	N002
MS4EC	MSTAR end mill (Metric type).....	I076	NKY	Flag wrench	N002
MS4JC	MSTAR end mill (Metric type).....	I064	NL	Pin	N014
MS4MC	MSTAR end mill (Metric type).....	I062	NL	Pin	N014
MS4MRB	MSTAR end mill (Metric type).....	I083	NNMU	Insert (For AHX440S type face mill) ...	K024,L041
MS4SC	MSTAR end mill (Metric type).....	I060	NNMU	Insert (For AHX440S/AHX475S/AHX640S type face mill)...	K024,L041,L046,L052
MS4XL	MSTAR end mill (Metric type).....	I066	NNMU130532ZEN	Insert (For AHX440S/AHX475S type face mill) ...	K024,L041,L046
MS4XL	MSTAR end mill (Inch type).....	I070	NNMU200608ZEN-HK	Insert (For AHX640S/AHX640W type face mill)...	K024,L052,L064
M-SCLCR	Screw clamp type boring bar (Heavy metal shank) ...	E012	NNMU200608ZEN-MK	Insert (For AHX640S/AHX640W type face mill)...	K024,L052,L064
MSDNN	Multiple clamp type holder.....	C016	NNMU200708ZEN-MP	Insert (For AHX640S type face mill) ...	K024,L052
MSDNN	Multiple clamp type holder.....	C016	NNMU200712ZER-L	Insert (For AHX640S type face mill) ...	K025,L052
MSE	MSE type drill (Metric type)	M148,M149,M151	NNMU200712ZER-MM	Insert (For AHX640S type face mill) ...	K024,L052
MSKNR/L	Multiple clamp type holder	C017	NP-CCGB21.51-GA2	CBN insert (Class G tolerance)	B044
MSKNR/L	Multiple clamp type holder	C017	NP-CCGW	CBN insert (Class G tolerance)	B046
MSKNR/L	Multiple clamp type holder	C017	NP-CCGW	CBN insert (Class G tolerance)	B044,B045
MSMHD	MSTAR end mill (Metric type).....	I053	NP-CCGW	CBN insert (Class G tolerance)	B045
MSMHZD	MSTAR end mill (Metric type).....	I056	NP-CCGW	CBN insert (Class G tolerance)	B045
MSMHZD	MSTAR end mill (Inch type).....	I058	NP-CCMH	CBN insert (Class M tolerance)	B063
MSP0300SB	MSP starter drill (Metric type).....	M152	NP-CCMW	CBN insert (Class M tolerance)	B063
MSRNR/L	Multiple clamp type holder	C014	NP-CNGA	CBN insert (Class G tolerance)	B029
MSRNR/L	Multiple clamp type holder	C014	NP-CNGA	CBN insert (Class G tolerance)	B028
MSRNR/L	Multiple clamp type holder	C014	NP-CNGA	CBN insert (Class G tolerance)	B029,B030
MSSHD	MSTAR end mill (Metric type).....	I052	NP-CNGA	CBN insert (Class G tolerance)	B028,B029,B030
MSSNR/L	Multiple clamp type holder	C015	NP-CNGA	CBN insert (Class G tolerance)	B029
MSSNR/L	Multiple clamp type holder	C015	NP-CNGA	CBN insert (Class G tolerance)	B028
M-SWLOR/L	Screw clamp type boring bar (Heavy metal shank) ...	E020	NP-CNMM	CBN insert (Class M tolerance)	B059
M-SWLOR/L	Screw clamp type boring bar (Heavy metal shank) ...	E020	NP-CPGB	CBN insert (Class G tolerance)	B047
MTANR/L	Multiple clamp type holder	C020	NP-CPMH	CBN insert (Class M tolerance)	B063
MTANR/L	Multiple clamp type holder	C020	NP-DCGW	CBN insert (Class G tolerance)	B048,B049
MTCNN	Multiple clamp type holder	C021	NP-DCMT	CBN insert (Class M tolerance)	B064
MTCNN	Multiple clamp type holder	C021	NP-DNGA	CBN insert (Class G tolerance)	B033
MTENN	Multiple clamp type holder	C021	NP-DNGA	CBN insert (Class G tolerance)	B031,B032
MTENN	Multiple clamp type holder	C021	NP-DNGA	CBN insert (Class G tolerance)	B034
MTENN	Multiple clamp type holder	C021	NP-DNMM	CBN insert (Class M tolerance)	B059
MTFNR/L	Multiple clamp type holder	C023	NP-GDCN2004PDSR3	Insert (For NF10000 type cutter)	K051
MTFNR/L	Multiple clamp type holder	C023	NP-SNGA	CBN insert (Class G tolerance)	B035
MTFNR/L	Multiple clamp type holder	C023	NP-SNGA	CBN insert (Class G tolerance)	B035
MTGNR/L	Multiple clamp type holder	C019	NP-SNM	CBN insert (Class M tolerance)	B060
MTGNR/L	Multiple clamp type holder	C019	NP-TCGW	CBN insert (Class G tolerance)	B050
MTJNR/L	Multiple clamp type holder	C018	NP-TNGA	CBN insert (Class G tolerance)	B036,B037
MTJNR/L	Multiple clamp type holder	C018	NP-TNGA	CBN insert (Class G tolerance)	B036
MTK1R/L	Clamp bridge	N015	NP-TNGA	CBN insert (Class G tolerance)	B037
MTRNR/L-123X	Multiple clamp type holder	C020	NP-TNMM	CBN insert (Class M tolerance)	B060
MTRNR/L-164	Multiple clamp type holder	C020	NP-TPGB	CBN insert (Class G tolerance)	B051,B052
MTTR/L43	Insert (For threading).....	H018	NP-TPMH	CBN insert (Class M tolerance)	B066
MVE	MVE type drill	M012—M072			
MVJNR/L	Multiple clamp type holder	C024			
MVLNR/L	Multiple clamp type holder	C026			
MVS	MVS type drill	M006—M072			
MVS	MVS type drill	M013—M063			

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
O			S		
NP-TPMX○○○R/LF	CBN insert (Class M tolerance).....	B066	S○	Clamp screw.....	N005
NP-VBGT○○○RF	CBN insert (Class G tolerance).....	B068	S○○	Clamp screw.....	N005
NP-VBGW○○○-○○2	CBN insert (Class G tolerance).....	B053	SBAHR○○○○	Boring holder.....	D047
NP-VCGT○○○RF	CBN insert (Class G tolerance).....	B068	SBAT○○○○○○L	Insert (For BAHR type holder).....	D047
NP-VCGW○○○-○○2	CBN insert (Class G tolerance).....	B054	SBAT○○○○○○L-B	Insert (For BAHR type holder).....	D047
NP-VNGA○○○-○○2	CBN insert (Class G tolerance).....	B038,B039	SBH○○○○○	Clamp screw.....	N002
NP-VNGA○○○-○○4	CBN insert (Class G tolerance).....	B038	SBH○○○○R	Holder (For MICRO-DEX/MICRO-MINI).....	E037,F243,G036
NP-VNMM○○○RF	CBN insert (Class M tolerance).....	B061	SC○○M○○S○○○S/L	Straight shank arbor (For Screw-in).....	L294
NP-WCGW○○○-○○3	CBN insert (Class G tolerance).....	B055	SC○○M○○S○○○SW/LW	Straight shank arbor (For Screw-in).....	L295
NP-WEEW13T3AG○R3C	Wiper CBN insert (For ASX445 type cutter)...	K052,L034	SC○○M○○S○○○-HSK63A	HSK shank arbor (For Screw-in).....	L296
NP-WFC42ZFER○	Wiper CBN insert (For BF407 type cutter)...	K052	SC○○M○○S10-BT○○	BT shank arbor (For Screw-in).....	L296
NP-WNGA432-○○3	CBN insert (Class G tolerance).....	B040	SCACR/L○○○○○○-SM	External front turning holder.....	D012
NP-WNGA432-G○WS3	CBN insert (Class G tolerance).....	B040	SCACR/L-○○○SM	External front turning holder.....	D008
NP-WNGA432-○○6	CBN insert (Class G tolerance).....	B040	SCLCR/L-○○○	Screw clamp type holder.....	C030
NS○○○	Clamp screw (For small tools holder).....	N004	SCLCR/L○○○○○○-SM	External front turning holder.....	D012
NS○○○W	Clamp screw (For small tools holder)...	N004,N005	SCLCR/L-○○○SM	External front turning holder.....	D008
P			SCMT○○○	Insert (Class M tolerance).....	A169
OEMX○○○○EER1-JS	Insert (For BOE type cutter).....	K033,L256	SCMT○○○FM	Insert (Class M tolerance).....	A168
OEMX○○○○ESR1	Insert (For BOE type cutter).....	K032,L256	SCMT○○○FP	Insert (Class M tolerance).....	A168
OEMX○○○○ETR○	Insert (For BOE type cutter).....	K050,K032,L256	SCMT○○○FV	Insert (Class M tolerance).....	A168
OEMX○○○○EOR1-JS	Insert (For BOE type cutter).....	K033,L256	SCMT○○○LM	Insert (Class M tolerance).....	A168
ORGW○○○N9	O ring.....	F233,F234	SCMT○○○LP	Insert (Class M tolerance).....	A168
Q			SCMT○○○MK	Insert (Class M tolerance).....	A169
PMC○○○R○○○AM○○○	PMC type end mill.....	L288	SCMT○○○MM	Insert (Class M tolerance).....	A169
PMF○○○○○A○○R	PMF type end mill (Metric type).....	L290	SCMT○○○MP	Insert (Class M tolerance).....	A168
PMFA13R	Cartridge (For PMF type cutter).....	L290	SCMT○○○MS	Insert (Class M tolerance).....	A169
PMR○○○○○○R	PMR type end mill.....	L291	SCMW○○○	Insert (Class M tolerance).....	A169
PMR○○○○○○A○○R	PMR type end mill.....	L291	SCU○○M○○S○○○S/L	Straight shank arbor (For Screw-in).....	L294
R			SCU○○M○○S○○○SW/LW	Straight shank arbor (For Screw-in).....	L295
RBH○○○○○A	Holder (For MICRO-DEX/MICRO-MINI).....	E034,F242,G035	S-DCLNR/L-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E021
RBH○○○○N	Holder (For MICRO-DEX/MICRO-MINI).....	E034,E036,F242,F243,G035,G036	S-DDUNR/L-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E021
RCGT○○○○M0-AZ	Insert (Class G tolerance).....	A167	SDEN42AEN	Insert (For Corner Angle 45° type cutter)...	K048
RCMT○○○○M0	Insert (Class M tolerance).....	A167	SDJCR/L-○○○	Screw clamp type holder.....	C031
RCMX○○○○M0	Insert (Class M tolerance).....	A167	SDJCR/L○○○○○○-SM	External front turning holder.....	D013
RCMX○○○○M0-RR	Insert (Class M tolerance).....	A167	SDJCR/L-○○○SM	External front turning holder.....	D009
RDMW○○○○M0E	Insert (For ARX type cutter).....	K027,L250	SDJER/L-○○○	Screw clamp type holder.....	C041
REMX○○○○○N	Insert (For BOE type cutter).....	K033,L256	SDKN○○AE○	Insert (For milling).....	K048
REMX○○○○○N-JS	Insert (For BOE type cutter).....	K033,L256	SDNCN-○○○	Screw clamp type holder.....	C031
RGEN2004○N	Insert (For SG20 type cutter).....	K038	SDNCR/L○○○○○○-SM	External front turning holder.....	D013
RNG○○	Insert (Class G tolerance).....	B042	SDNCR/L-○○○SM	External front turning holder.....	D009
RNMG○○	Insert (Class M tolerance).....	A119	S-DSKNR/L-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E022
RPHT○○○○M0E4-○	Insert (For ARP type cutter).....	K027,L243	S-DTFNR/L-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E022
RPMT○○○○○M0E4-○	Insert (For ARP type cutter).....	K027,L243	S-DVUNR/L-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E023
RPMT○○○○○E-JS	Insert (For BRP type cutter).....	K033,L253	S-DWLNRL-○○○-C	DOUBLE CLAMP DIMPLE BAR.....	E023
RPMW○○○○○E	Insert (For BRP type cutter).....	K033,L253	SDXCR/L-○○○	Screw clamp type holder.....	C032
RS○○○○T/TS	Clamp screw.....	N005	SECN○○AFON1	Insert (For SE445/545 type face mill).....	K037
RTG○○A	Insert (Class G tolerance).....	A193	SECN42AFFR1	Insert (For SE445 type face mill).....	K052
			SEEN○○AFON○	Insert (For SE445/545 type face mill)...	K037,K038
			SEEN42EFOR1	Insert (For SE415 type face mill).....	K037
			SEEN53EFER1	Insert (For SE515 type face mill).....	K038
			SEER53AFEN-JS	Insert (For SE445/545 type cutter).....	K038
			SEER42EFER-JS	Insert (For SE415 type cutter).....	K037
			SEER4○AFEN-JS	Insert (For Corner Angle 45° type cutter)...	K048
			SEET13T3AGEN-JL	Insert (For ASX445 type cutter).....	K028,L033
			SEGT13T3AGFN-JP	Insert (For ASX445 type cutter).....	K029,L033
			SEKN42AFTN	Insert (For SE445/545 type cutter).....	K037
			SEKN○○AFON1	Insert (For SE445/545 type cutter)....	K037,K038
			SEKN42AGTN	Insert (For Corner Angle 45° type cutter)...	K048
			SEKN42EFTR	Insert (For SE415 type face mill).....	K037

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
SEKN42EFOR1	Insert (For SE415 type face mill)	K037	SOGX000000-UN	Insert (For MVX type drill)	M180,M189
SEMT13T3AGSN-FT	Insert (For ASX445 type cutter)	K029,L033	SOMT12T308PEER/L-JM	Insert (For ASX400 type cutter)	K028,L086,L095
SEMT13T3AGSN-JH	Insert (For ASX445 type cutter)	K029,L033	SOMT12T308PEER-JH	Insert (For ASX400 type cutter)	K028,L086
SEMT13T3AGSN-JM	Insert (For ASX445 type cutter)	K029,L033	SOMT12T320PEER-FT	Insert (For ASX400 type cutter)	K028,L086
SETK00	Clamp bridge	N015	SOMX000000-UM	Insert (For MVX type drill)	M180,M189
SETS01	Clamp screw	N005	SOMX000000-US	Insert (For MVX type drill)	M180,M189
SFAN42ZFFR/L2	Insert (For BF407 type face mill)	K032	SOMX000000-UH	Insert (For MVX type drill)	M180,M189
SFC/FM000000	Clamp screw	N002	SOMX000000-UN	Insert (For MVX type drill)	M180,M189
SFCN42ZFFR2	Insert (For BF407 type face mill)	K032,K050	SONX1206PER/L	Insert (For VOX400/VOS400 type cutter)	K046,L079,L094
S-FSCLPR/L-000-C	Screw clamp DIMPLE BAR	E006	SPEN42EEER/L1	Insert (For FBP415 type face mill)	K034
S-FSTUPR/L-000-C	Screw clamp DIMPLE BAR	E007	SPEN42EETR1	Insert (For FBP415 type face mill)	K050
SH000-FSDUCL00	DIMPLE SLEEVE holder	D039,D040	SPER42EEER-JS	Insert (For FBP415 type cutter)	K035
SL0000-90	HSK boring bar sleeve	H022	SPG000	Insert (Class G tolerance)	A194,B056,B072
SLCS105	Clamp screw	N005	SPGR321R	Insert (Class G tolerance)	A194
SL-ONEN120404ASN	Insert (For AOX445 type cutter)	K050,L069	SPGX000	Insert (Class G tolerance)	A170,B064
S-MCLNR/L-000	Multiple clamp type holder	E024	SPKN00EDR	Insert (For Corner Angle 15° type cutter)	K048
S-MDUNR/L-000	Multiple clamp type holder	E024	SPM00000	Clamp screw	N002
S-MSKNR/L-000	Multiple clamp type holder	E025	SPMB1204APT	Insert (For BSP type end mill)	K033
S-MTFNR/L-000	Multiple clamp type holder	E025	SPMM432A	Insert (For TBE1 type end mill)	K042
S-MTFNR/L-000X	Multiple clamp type holder	E025	SPMN000	Insert (Class M tolerance)	A194,K049
S-MVUNR/L-000	Multiple clamp type holder	E026	SPMN000T	Insert (For 11° positive type end mill)	K049
S-MWLNRL-000	Multiple clamp type holder	E026	SPMR000	Insert (Class M tolerance)	A194
SNG000	Insert (Class G tolerance)	A145,B042,B062	SPMT000	Insert (Class M tolerance)	A170
SNGA000	Insert (Class G tolerance)	A125,B035,B060	SPMW000	Insert (For CFSP type end mill)	A170,K034,L261
SNGG000R/L	Insert (Class G tolerance)	A123	SPMX120408-JM	Insert (For SPX type end mill)	K039,L183
SNGU140812AN000	Insert (For WSX445 type cutter)	K047,L025	SPMX120408-WH	Insert (For SPX type end mill)	K039,L183
SNMA000	Insert (Class M tolerance)	A125	SPNN42EEER/L1	Insert (For FBP415 type face mill)	K035
SNMG000	Insert (Class M tolerance)	A123	SPSCN42	Shim	N011
SNMG000C	Insert (Class M tolerance)	A121	SPSDN32	Shim	N012
SNMG000FH	Insert (Class M tolerance)	A120	SPSSN42	Shim	N012
SNMG000FP	Insert (Class M tolerance)	A120	SPSTN32	Shim	N012
SNMG000FS	Insert (Class M tolerance)	A120	SPSVN32	Shim	N012
SNMG000GH	Insert (Class M tolerance)	A124	SPX4-000A24A058RA	SPX type end mill (Metric type)	L182
SNMG000GK	Insert (Class M tolerance)	A122	SPX4R000000A058A	SPX type end mill (Metric type)	L182
SNMG000GM	Insert (Class M tolerance)	A122	SPX4R05000WN0	SPX type end mill	L180
SNMG000LK	Insert (Class M tolerance)	A120	SPX4R3200CAT50N0	SPX type end mill	L180
SNMG000LM	Insert (Class M tolerance)	A120	SPX4UR00000A22A	SPX type end mill	L181
SNMG000LP	Insert (Class M tolerance)	A120	SRDCN-0000M	Screw clamp type holder	C033
SNMG000MA	Insert (Class M tolerance)	A122	SRDPN-1612	Screw clamp type holder	C040
SNMG000MH	Insert (Class M tolerance)	A122	SRDPR/L-1612	Screw clamp type holder	C040
SNMG000MK	Insert (Class M tolerance)	A122	SRFHU00AM0000	SRF screw-in type end mill (Metric type)	L267
SNMG000MM	Insert (Class M tolerance)	A121	SRFH00AM0000	SRF screw-in type end mill (Metric type)	L267,L268
SNMG000MP	Insert (Class M tolerance)	A121	SRFH00S000	SRF type end mill (Metric type)	L264,L265
SNMG000MS	Insert (Class M tolerance)	A123	SRFH00S00L000	SRF type end mill (Metric type)	L264
SNMG000R/L1G	Insert (Class M tolerance)	A121	SRFH00S00E00	SRF type end mill (Metric type)	L265
SNMG000RK	Insert (Class M tolerance)	A124	SRFH00S00LW/MW/EW	SRF type end mill (Metric type)	L266
SNMG000RM	Insert (Class M tolerance)	A124	SRFT00	Insert (For SRF type cutter)	K040,L269
SNMG000RP	Insert (Class M tolerance)	A123	SRFT0000	Insert (For SRF type cutter)	K040,L269
SNMG000RS	Insert (Class M tolerance)	A124	SRFU00S00L/M	SRF type end mill	L262
SNMG000SA	Insert (Class M tolerance)	A121	SRFU00S00LW/MW	SRF type end mill	L263
SNMG000SH	Insert (Class M tolerance)	A121	SRG00C/E	SRM2 type end mill	K041,K042,L281,L287
SNMG000SY	Insert (Class M tolerance)	A121	SRGCR/L-0000M	Screw clamp type holder	C033
SNMM000HL	Insert (Class M tolerance)	A125	SRK1R	Clamp bridge	N015
SNMM000HM	Insert (Class M tolerance)	A125	SRM000C/E	Insert (For SRM2 type cutter)	K041,L280
SNMM000HR	Insert (Class M tolerance)	A125	SRM000C/E-M	Insert (For SRM2 type cutter)	K041,L280
SNMM000HV	Insert (Class M tolerance)	A125	SRM000C/E-M	Insert (For SRM2 type end mill)	K041,K042,L281
SNMM000HX	Insert (Class M tolerance)	A125	SRM2000AM00S/L00	SRM2 type screw-in end mill	L278,L279
SNMM000HZ	Insert (Class M tolerance)	A124	SRM200SAS2/M2/L2/L4	SRM2 type end mill	L275
SNMN000	Insert (Class M tolerance)	A145,K049	SRM2000SOM/L/F/LF/LL	SRM2 type end mill	L276,L277
SNMU140812ANE00	Insert (For WSX445 type cutter)	K047,L025	SRM2000SNLS/M	SRM2 type end mill	L286
SOET12T308PEER-JL	Insert (For ASX400 type cutter)	K028,L086	SRM2000WNLS/M/L/X	SRM2 type end mill	L286
SOGT12T308PEFR-JP	Insert (For ASX400 type cutter)	K028,L086			

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
SRM2500MNL5/M	SRM2 type end mill	L286	TCGW000F	Insert (Class G tolerance)	A174
SRS5	Clamp screw (For SRE type cutter)	N005	TCGW000FS	Insert (Class G tolerance)	B050
SSBCR/L-000	Screw clamp type holder	C034	TCMT000	Insert (Class M tolerance)	A174
S-SCLCR/L-000	Screw clamp type boring bar	E012	TCMT000FM	Insert (Class M tolerance)	A171
S-SDQCR/L-000	Screw clamp type boring bar	E013	TCMT000FP	Insert (Class M tolerance)	A171
S-SDUCR/L-000	Screw clamp type boring bar	E014	TCMT000FV	Insert (Class M tolerance)	A171
S-SL5NR00	Grooving and threading boring bar	F239,G032	TCMT000LM	Insert (Class M tolerance)	A172
SSC/SD/SP/SR/SS000000	Clamp screw	N002	TCMT000LP	Insert (Class M tolerance)	A172
SSSCR/L-000	Screw clamp type holder	C034	TCMT000LS	Insert (Class M tolerance)	A172
S-SSKCR/L-000	Screw clamp type boring bar	E015	TCMT000MK	Insert (Class M tolerance)	A173
S-STFER/L-000	AL type boring bar	E028	TCMT000MM	Insert (Class M tolerance)	A173
S-STUCR/L-000	Screw clamp type boring bar	E015	TCMT000MP	Insert (Class M tolerance)	A173
S-SVQCR/L-000	Screw clamp type boring bar	E016	TCMT000MS	Insert (Class M tolerance)	A173
S-SVUCR/L-000	Screw clamp type boring bar	E017	TCMW000	Insert (Class M tolerance)	A174,B065
S-SWUCR/L-000	Screw clamp type boring bar	E019	TECN32PE0R1W	Insert (For NSE300 type face mill)	K036
STASX000N	Shim (For ASX445/400 type face mill)	N012	TECN43PE0R1	Insert (For NSE400 type face mill)	K036
STAW000000	STAW type drill (Inch type)	M196-M199	TEEN000PE0R1	Insert (For NSE300/400 type face mill)	K036
STAW000000S00	STAW type drill (Metric type)	M200-M203	TEER000PEER-JS	Insert (For NSE300/400 type face mill)	K036
STAWK0000TG	Insert (For STAW type drill)	M205,M208,M209	TEGX000	Insert (Class G tolerance)	B070
STAWN00000T	Insert (For STAW type drill)	M204,M207	TEGX000R/L	Insert (Class G tolerance)	A175,B070
STAWN00000TH	Insert (For STAW type drill)	M204,M206,M207	TEKN43PETR	Insert (For NSE400 type face mill)	K036
STFCR/L-000	Screw clamp type holder	C035	TEKN43PE0R1	Insert (For NSE400 type face mill)	K036
STFER/L-000	AL type holder	C042	TIP00D	Torx plus Wrench	N002
STGCR/L-000	Screw clamp type holder	C035	TIP00F	Torx plus Wrench	N002
STGER/L-000	AL type holder	C042	TIP00L	Torx plus Wrench	N002
SUFT00R00	Insert (For SRF type cutter)	K040,L270	TIP00R	Torx plus Wrench	N002
SVHBR/L-000	Screw clamp type holder	C029	TIP00T	Torx plus Wrench	N002
SVJBR/L-000	Screw clamp type holder	C028	TIP00W	Torx plus Wrench	N002
SVJBR/L00000000-SM	External front turning holder	D014	TKY00D	Driver wrench	N002
SVJBR/L-000SM	External front turning holder	D010	TKY00F	Flag wrench	N002
SVJCR/L-000	Screw clamp type holder	C036	TKY00L	Long L-wrench	N002
SVJCR/L-000B-SM	External front turning holder	D011	TKY00R	L-wrench	N002
SVJCR/L00000JX00-SM	External front turning holder	D015	TKY00T	T-wrench	N002
SVJDR/L-000	AL type holder	C043	TKY00W	Flag wrench	N002
SVLPR/L00000000-SM	External front turning holder	D014	TNG000	Insert (Class G tolerance)	A146,B043
SVLPR/L-000SM	External front turning holder	D010	TNGA000	Insert (Class G tolerance)	A133,B037,B060
SVPCR/L-000	Screw clamp type holder	C036	TNGG000PK	Insert (Class G tolerance)	A126
SVPDR/L-000	AL type holder	C043	TNGG000R/L	Insert (Class G tolerance)	A131
SVPPR/L00000000-SM	External front turning holder	D015	TNGG000R/LF	Insert (Class G tolerance)	A127
SVVBN-000	Screw clamp type holder	C028	TNGG000R/LFS	Insert (Class G tolerance)	A126
SVVBR/L00000000-SM	External front turning holder	D015	TNGG000R/LK	Insert (Class G tolerance)	A128
SVVBR/L-000SM	External front turning holder	D011	TNMA000	Insert (Class M tolerance)	A132
SWLCR/L-000	Screw clamp type holder	C037	TNMG000	Insert (Class M tolerance)	A129,A130
SXZCR/L-000	Double clamp type holder	C038	TNMG000C	Insert (Class M tolerance)	A128
SXZCR/L00000015	Double clamp type holder (Inch type)	C038	TNMG000FH	Insert (Class M tolerance)	A126
T			TNMG000FP	Insert (Class M tolerance)	A126
TAWC12T301-45GM	Insert (For TAW type drill)	K053	TNMG000FS	Insert (Class M tolerance)	A126
TAWKH0000TG	Insert (For TAW type drill)	M223	TNMG000FY	Insert (Class M tolerance)	A126
TAWLN/MN/SN0000	TAW type drill (Inch type)	M212-M217	TNMG000GH	Insert (Class M tolerance)	A132
TAWLN/MN/SN0000S00	TAW type drill (Metric type)	M218,M219	TNMG000GK	Insert (Class M tolerance)	A129
TAWNH00000T	Insert (For TAW type drill)	M221,M222	TNMG000GM	Insert (Class M tolerance)	A129
TBG000	Insert (Class G tolerance)	B057	TNMG000LK	Insert (Class M tolerance)	A127
TCG000	Insert (Class G tolerance)	A195	TNMG000LM	Insert (Class M tolerance)	A127
TCGT000AZ	Insert (Class G tolerance)	A171	TNMG000LP	Insert (Class M tolerance)	A127
TCGT000FJ-P	Insert (Class G tolerance)	A171	TNMG000LS	Insert (Class M tolerance)	A127
TCGT000MJ	Insert (Class G tolerance)	A173	TNMG000MA	Insert (Class M tolerance)	A129
TCGT000MJ-P	Insert (Class G tolerance)	A173	TNMG000MH	Insert (Class M tolerance)	A129
TCGT000MR/LF	Insert (Class G tolerance)	A172	TNMG000MJ	Insert (Class M tolerance)	A128
TCGT000R/LF	Insert (Class G tolerance)	A172	TNMG000MK	Insert (Class M tolerance)	A129
TCGW000	Insert (Class G tolerance)	A174,B065	TNMG000MM	Insert (Class M tolerance)	A129
			TNMG000MP	Insert (Class M tolerance)	A128
			TNMG000MS	Insert (Class M tolerance)	A130

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
TNMG $\circ\circ\circ$ R/L1G	Insert (Class M tolerance)	A128	VBMT $\circ\circ\circ$ LM	Insert (Class M tolerance)	A180
TNMG $\circ\circ\circ$ R/L2G	Insert (Class M tolerance)	A131	VBMT $\circ\circ\circ$ LP	Insert (Class M tolerance)	A180
TNMG $\circ\circ\circ$ R/LES	Insert (Class M tolerance)	A130	VBMT $\circ\circ\circ$ LS	Insert (Class M tolerance)	A180
TNMG $\circ\circ\circ$ RK	Insert (Class M tolerance)	A131	VBMT $\circ\circ\circ$ MK	Insert (Class M tolerance)	A182
TNMG $\circ\circ\circ$ RM	Insert (Class M tolerance)	A131	VBMT $\circ\circ\circ$ MM	Insert (Class M tolerance)	A182
TNMG $\circ\circ\circ$ RP	Insert (Class M tolerance)	A131	VBMT $\circ\circ\circ$ MP	Insert (Class M tolerance)	A181
TNMG $\circ\circ\circ$ RS	Insert (Class M tolerance)	A132	VBMT $\circ\circ\circ$ MS	Insert (Class M tolerance)	A182
TNMG $\circ\circ\circ$ SA	Insert (Class M tolerance)	A127	VBMT $\circ\circ\circ$ MV	Insert (Class M tolerance)	A182
TNMG $\circ\circ\circ$ SH	Insert (Class M tolerance)	A127	VBMT $\circ\circ\circ$ SV	Insert (Class M tolerance)	A180
TNMG $\circ\circ\circ$ SY	Insert (Class M tolerance)	A128	VBMW $\circ\circ\circ$	Insert (Class M tolerance)	A183
TNMM $\circ\circ\circ$ HL	Insert (Class M tolerance)	A132	VC2C	MIRACLE end mill (Metric type)	I122
TNMM $\circ\circ\circ$ HZ	Insert (Class M tolerance)	A132	VC4JRB	MIRACLE end mill (Metric type)	I120
TNMM $\circ\circ\circ$	Insert (Class M tolerance)	A146	VCGT $\circ\circ\circ$ AZ	Insert (Class G tolerance)	A184
TNMX $\circ\circ\circ$ MW	Insert (Class M tolerance)	A130	VCGT $\circ\circ\circ$ R/LF	Insert (Class G tolerance)	A184
TNMX $\circ\circ\circ$ SW	Insert (Class M tolerance)	A127	VCGT $\circ\circ\circ$ MLS	Insert (Class G tolerance)	A185
TPEW1303ZP $\circ$ R2	Insert (For PMF type end mill) ... K036,K052,L290		VCGT $\circ\circ\circ$ MLS-P	Insert (Class G tolerance)	A185
TPG $\circ\circ\circ$	Insert (Class G tolerance)	A197,B057,B072	VCLD	MIRACLE end mill (Metric type)	I113
TPGH $\circ\circ\circ$ R/LFS	Insert (Class G tolerance)	A176	VCMT $\circ\circ\circ$	Insert (Class M tolerance)	A186
TPGR $\circ\circ\circ$ R/L	Insert (Class G tolerance)	A196	VCMT $\circ\circ\circ$ FM	Insert (Class M tolerance)	A184
TPGT $\circ\circ\circ$ R/LF	Insert (Class G tolerance)	B066	VCMT $\circ\circ\circ$ FP	Insert (Class M tolerance)	A184
TPGV $\circ\circ\circ$ R/LF	Insert (Class G tolerance)	B067	VCMT $\circ\circ\circ$ FV	Insert (Class M tolerance)	A184
TPGX $\circ\circ\circ$	Insert (Class G tolerance)	A178,B052,B067	VCMT $\circ\circ\circ$ LM	Insert (Class M tolerance)	A185
TPGX $\circ\circ\circ$ R/L	Insert (Class G tolerance)	A177	VCMT $\circ\circ\circ$ LP	Insert (Class M tolerance)	A185
TPKN $\circ\circ\circ$ POR	Insert (For Corner Angle 0° type cutter) K048		VCMT $\circ\circ\circ$ LS	Insert (Class M tolerance)	A185
TPMH $\circ\circ\circ$ FV	Insert (Class M tolerance)	A176	VCMT $\circ\circ\circ$ MK	Insert (Class M tolerance)	A186
TPMH $\circ\circ\circ$ MV	Insert (Class M tolerance)	A178	VCMT $\circ\circ\circ$ MM	Insert (Class M tolerance)	A185
TPMH $\circ\circ\circ$ SV	Insert (Class M tolerance)	A177	VCMT $\circ\circ\circ$ MP	Insert (Class M tolerance)	A185
TPMN $\circ\circ\circ$	Insert (Class M tolerance)	A196,K049	VCMT $\circ\circ\circ$ MS	Insert (Class M tolerance)	A186
TPMR $\circ\circ\circ$	Insert (Class M tolerance)	A196	VCMT $\circ\circ\circ$ MV	Insert (Class M tolerance)	A186
TPMT $\circ\circ\circ$ MQ	Insert (Class M tolerance)	A178	VCMT $\circ\circ\circ$ SV	Insert (Class M tolerance)	A185
TPMT $\circ\circ\circ$ SQ	Insert (Class M tolerance)	A176	VCMW $\circ\circ\circ$	Insert (Class M tolerance)	A186
TPMX $\circ\circ\circ$	Insert (Class M tolerance)	A178	VCPSRB	MIRACLE end mill (Metric type)	I114,I118
TPMX $\circ\circ\circ$ L	Insert (Class M tolerance)	A177	VDGX $\circ\circ\circ$ R/L	Insert (Class G tolerance)	A187
TPS $\circ\circ$	Clamp screw	N005	VDGX $\circ\circ\circ$ R/LF	Insert (Class G tolerance)	B071
TPS $\circ\circ$ - $\circ$	Clamp screw	N005	VF2MV	IMPACT MIRACLE end mill (Metric type)	I186
TS $\circ$	Clamp screw	N006	VF2SB	IMPACT MIRACLE end mill (Inch type)	I203
TS $\circ\circ$	Clamp screw	N006	VF2WB	IMPACT MIRACLE end mill (Metric type)	I202
TS $\circ\circ\circ$	Clamp screw	N006	VF2XL	IMPACT MIRACLE end mill (Metric type)	I183
TSS04005	Radial screw	N006	VF2XLB	IMPACT MIRACLE end mill (Metric type)	I206
TSS04505S	Radial screw	N006	VF2XLB	IMPACT MIRACLE end mill (Inch type)	I212
TTAHR/L- $\circ\circ\circ$	External threading holder	D035	VF2XLBS	IMPACT MIRACLE end mill (Metric type)	I205
TTAHR/L $\circ\circ\circ\circ$	External threading holder	D036	VF3XB	IMPACT MIRACLE end mill (Metric type)	I214
TTAT $\circ\circ\circ\circ\circ\circ\circ$ R/L $\circ$ -B	Threading insert	D035,D036	VF4MB	IMPACT MIRACLE end mill (Metric type)	I220
V			VF4MV	IMPACT MIRACLE end mill (Metric type)	I188
VAS400	VAS400 type side cutter (Metric type)	L090	VF6MHV	IMPACT MIRACLE end mill (Metric type)	I189
VAS400UA $\circ\circ\circ\circ\circ\circ\circ$ R/L $\circ\circ\circ\circ$	VAS400 type side cutter	L088	VF6MHVRB	IMPACT MIRACLE end mill (Metric type)	I242
VAS400UA $\circ\circ\circ\circ\circ\circ\circ$ N $\circ\circ\circ\circ$	VAS400 type side cutter	L089	VF6SVRCH	IMPACT MIRACLE end mill (Metric type)	I199
VAS500	VAS500 type side cutter (Metric type)	L092	VF8MHVCH	IMPACT MIRACLE end mill (Metric type)	I190
VBET $\circ\circ\circ$ R/LSN	Insert (Class E tolerance)	A183	VF8MHVRBCH	IMPACT MIRACLE end mill (Metric type)	I244
VBET $\circ\circ\circ$ R/LSR	Insert (Class E tolerance)	A183	VFFDRB	IMPACT MIRACLE end mill (Metric type)	I222
VBET $\circ\circ\circ$ R/LWSN	Insert (Class E tolerance)	A183	VFHVRB	IMPACT MIRACLE end mill (Metric type) ... I224,I232	
VBGT $\circ\circ\circ$ FJ	Insert (Class G tolerance)	A179	VFHVRB	IMPACT MIRACLE end mill (Inch type)	I230
VBGT $\circ\circ\circ$ FJ-P	Insert (Class G tolerance)	A179	VFMD	IMPACT MIRACLE end mill (Metric type)	I192
VBGT $\circ\circ\circ$ MJ	Insert (Class G tolerance)	A181	VFMD	IMPACT MIRACLE end mill (Inch type)	I194
VBGT $\circ\circ\circ$ MJ-P	Insert (Class G tolerance)	A181	VFMDB	IMPACT MIRACLE end mill (Metric type)	I238
VBGT $\circ\circ\circ$ R/LF	Insert (Class G tolerance)	A180	VFMFPR	IMPACT MIRACLE end mill (Metric type)	I200
VBMT $\circ\circ\circ$	Insert (Class M tolerance)	A182	VFMHVRBCH	IMPACT MIRACLE end mill (Metric type)	I240
VBMT $\circ\circ\circ$ FM	Insert (Class M tolerance)	A179	VFR2SB	IMPACT MIRACLE REVOLUTION end mill (Metric type) ... I248	
VBMT $\circ\circ\circ$ FP	Insert (Class M tolerance)	A179	VFR2SSB	IMPACT MIRACLE REVOLUTION end mill (Metric type) ... I246	
VBMT $\circ\circ\circ$ FV	Insert (Class M tolerance)	A179	VFR2SBF	IMPACT MIRACLE REVOLUTION end mill (Metric type) ... I250	
			VFSD	IMPACT MIRACLE end mill (Metric type)	I191
			VFSDRB	IMPACT MIRACLE end mill (Metric type)	I236

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
VFSFPR	IMPACT MIRACLE end mill (Metric type).....	I196	VQMHZV	SMART MIRACLE end mill (Metric type).....	I124
VFSFPRCH	IMPACT MIRACLE end mill (Metric type).....	I198	VQMHZV	SMART MIRACLE end mill (Inch type).....	I130
VFX5-○○○○○○A○○R	VFX5 type end mill (Metric type)	L187	VQMHZVOH	SMART MIRACLE end mill (Metric type).....	I134
VFX5UR○○○○○○A○○	VFX5 type end mill	L186	VQMHZVOH	SMART MIRACLE end mill (Inch type).....	I138
VFX6-○○○A○○A○○R	VFX6 type end mill (Metric type)	L191	VQT5MVRB	SMART MIRACLE end mill with coolant hole ...	I178
VFX6UR○○○○○○A○○	VFX6 type end mill	L190	VQT6UR	SMART MIRACLE BARREL end mill	I180
VNGA○○○	Insert (Class G tolerance).....	A137, B039, B061	VQSVR	SMART MIRACLE end mill (Metric type).....	I155
VNGG○○○FJ	Insert (Class G tolerance).....	A134	VQXL	SMART MIRACLE end mill (Metric type).....	I152
VNGG○○○R/L	Insert (Class G tolerance).....	A137	W		
VNGG○○○R/LF	Insert (Class G tolerance).....	A134			
VNGM○○○MJ	Insert (Class G tolerance).....	A135	WA-M10	Washer	F236
VNMA○○○	Insert (Class M tolerance)	A137	WBGTO○○R/LF	Insert (Class G tolerance).....	A189
VNMG○○○	Insert (Class M tolerance)	A137	WBMT○○○R/LMV	Insert (Class M tolerance)	A189
VNMG○○○FH	Insert (Class M tolerance)	A134	WCGTO○○FJ-P	Insert (Class G tolerance).....	A190
VNMG○○○FP	Insert (Class M tolerance)	A134	WCGTO○○MJ	Insert (Class G tolerance).....	A190
VNMG○○○FS	Insert (Class M tolerance)	A134	WCGTO○○MJ-P	Insert (Class G tolerance).....	A190
VNMG○○○GK	Insert (Class M tolerance)	A136	WCGTO○○R/L	Insert (Class G tolerance).....	A190
VNMG○○○GM	Insert (Class M tolerance)	A136	WCMT○○○	Insert (Class M tolerance)	A190
VNMG○○○LK	Insert (Class M tolerance)	A135	WCMW○○○	Insert (Class M tolerance)	B069
VNMG○○○LM	Insert (Class M tolerance)	A135	WCS503507H	Shim screw	N007
VNMG○○○LP	Insert (Class M tolerance)	A134	WEC○○AF○R5C	Wiper insert (For SE445/545 type face mill) ...	K038, K052
VNMG○○○LS	Insert (Class M tolerance)	A135	WEC42EF○R5C	Wiper insert (For SE415 type face mill).....	K037
VNMG○○○MA	Insert (Class M tolerance)	A136	WEEW13T3AG○R8C	Wiper insert (For ASX445 type face mill) ...	K029, L034
VNMG○○○MH	Insert (Class M tolerance)	A136	WFC42ZF2	Wiper insert (For BF407 type face mill).....	K052
VNMG○○○MJ	Insert (Class M tolerance)	A135	WJX14-○○○A○○AR	WJX type face mill (Metric type).....	L227, L228
VNMG○○○MK	Insert (Class M tolerance)	A136	WJX14R○○○○○○A	WJX type face mill (Metric type).....	L227, L228
VNMG○○○MM	Insert (Class M tolerance)	A136	WJX14R○○○○○SA42S/L	WJX type end mill.....	L230
VNMG○○○MP	Insert (Class M tolerance)	A135	WJX14UR○○○○○○○A	WJX type face mill.....	L225
VNMG○○○MS	Insert (Class M tolerance)	A137	WJX14UR○○○○○○○AA	WJX type face mill.....	L224
VNMG○○○SA	Insert (Class M tolerance)	A135	WNEU1305ZEN4C-M	Wiper insert (For AHX440S type face mill) ...	K024, L041
VNMG○○○SH	Insert (Class M tolerance)	A135	WNEU2007ZEN7C-M	Wiper insert (For AHX640S type face mill) ...	K025, L052
VOS400	VOS400 type side cutter.....	L094	WNEU2006ZEN7C-WK	Wiper insert (For AHX640S/AHX640W type face mill) ...	K025, L052, L064
VOX400-○○○A○○R	VOX400 type face mill (Metric type)	L078	WNEU2007ZEN7C-WP	Wiper insert (For AHX640S type face mill) ...	K025, L052
VOX400R○○○○○○	VOX400 type face mill (Metric type).....	L077	WNGU1406ANEN8C-M	Wiper insert (For WSX445 type cutter) ...	K048, L025
VOX400UR○○○○○	VOX400 type face mill	L076	WNMA○○○	Insert (Class M tolerance)	A142
VPET○○○R/LSRF	Insert (Class E tolerance).....	A188	WNMG○○○	Insert (Class M tolerance)	A141
VPGT○○○MSMG	Insert (Class G tolerance).....	A188	WNMG○○○C	Insert (Class M tolerance)	A139
VPX200-○○○A○○AR	VPX200 type face mill (Metric type)	L129	WNMG○○○FH	Insert (Class M tolerance)	A138
VPX200R○○○○AM○○○	VPX200 type screw-in end mill (Metric type) ...	L128	WNMG○○○FP	Insert (Class M tolerance)	A138
VPX200R○○○○SA○○S/L	VPX200 type end mill (Metric type)	L127	WNMG○○○FS	Insert (Class M tolerance)	A138
VPX200UR○○○○○○○	VPX200 type face mill	L126	WNMG○○○FY	Insert (Class M tolerance)	A138
VPX200UR○○○○○AM○○○	VPX200 type screw-in end mill.....	L125	WNMG○○○GH	Insert (Class M tolerance)	A142
VPX200UR○○○○○FA/SA○○S	VPX200 type end mill	L124	WNMG○○○GJ	Insert (Class M tolerance)	A142
VPX300-○○○A○○AR	VPX300 type face mill (Metric type)	L146	WNMG○○○GK	Insert (Class M tolerance)	A140
VPX300R○○○○AM○○○	VPX300 type screw-in end mill (Metric type) ...	L145	WNMG○○○GM	Insert (Class M tolerance)	A140
VPX300R○○○○○CA	VPX300 type face mill (Metric type)	L146	WNMG○○○OLK	Insert (Class M tolerance)	A139
VPX300R○○○○○SA○○S/L	VPX300 type end mill (Metric type)	L144	WNMG○○○LM	Insert (Class M tolerance)	A138
VPX300UR○○○○○○○	VPX300 type face mill	L142	WNMG○○○LP	Insert (Class M tolerance)	A138
VPX300UR○○○○○AM○○○	VPX300 type screw-in end mill.....	L141	WNMG○○○LS	Insert (Class M tolerance)	A139
VPX300UR○○○○○FA/SA○○○	VPX300 type end mill	L140	WNMG○○○MA	Insert (Class M tolerance)	A141
VQ4SVB	SMART MIRACLE end mill (Metric type).....	I158	WNMG○○○MH	Insert (Class M tolerance)	A141
VQ4SVB	SMART MIRACLE end mill (Inch type).....	I160	WNMG○○○MJ	Insert (Class M tolerance)	A139
VQ6MHVCH	SMART MIRACLE end mill with coolant hole ...	I175	WNMG○○○MK	Insert (Class M tolerance)	A140
VQ6MHVRBCH	SMART MIRACLE end mill with coolant hole ...	I176	WNMG○○○MM	Insert (Class M tolerance)	A140
VQJHV	SMART MIRACLE end mill (Metric type).....	I148	WNMG○○○MP	Insert (Class M tolerance)	A140
VQJHV	SMART MIRACLE end mill (Inch type).....	I150	WNMG○○○MS	Insert (Class M tolerance)	A141
VQMHV	SMART MIRACLE end mill (Metric type).....	I141	WNMG○○○MW	Insert (Class M tolerance)	A141
VQMHV	SMART MIRACLE end mill (Inch type).....	I145	WNMG○○○RK	Insert (Class M tolerance)	A142
VQMHVRB	SMART MIRACLE end mill (Metric type).....	I162	WNMG○○○RM	Insert (Class M tolerance)	A142
VQMHVRB	SMART MIRACLE end mill (Inch type).....	I167	WNMG○○○RP	Insert (Class M tolerance)	A141
VQMHVRBF	SMART MIRACLE end mill (Metric type).....	I170			
VQMHVRBF	SMART MIRACLE end mill (Inch type).....	I172			

INDEX FOR TOOL NUMBER

ORDER NUMBER	PRODUCT NAME	PAGE	ORDER NUMBER	PRODUCT NAME	PAGE
WNMG○○○RS	Insert (Class M tolerance)	A142			
WNMG○○○SA	Insert (Class M tolerance)	A139			
WNMG○○○SH	Insert (Class M tolerance)	A139			
WNMG○○○SW	Insert (Class M tolerance)	A139			
WNMG○○○SY	Insert (Class M tolerance)	A139			
WOEW12T308PE○R8C	Wiper insert (For ASX400 type cutter) ...	K028,L086			
WOEX1206PER5C	Wiper insert (For VOX400 type cutter) ...	K046,L079			
WPC42EEER/L10C	Wiper insert (For FBP415 type cutter)	K035			
WPC42EETR10C	Wiper insert (For FBP415 type cutter)	K052			
WPGT○○○	Insert (Class G tolerance)	B069			
WPGT○○○R/LFS	Insert (Class G tolerance)	A191			
WPMT○○○MV	Insert (Class M tolerance)	A191			
WS○○○○○T	Clamp screw (For TAW type drill)	N007			
WS○○○○○TPS	Internal screw (For STAW type drill) ...	M210,N007			
WS○LH	Stopper (For STAW type drill)	M210,N007			
WSX445-○○○○○○○	WSX445 type face mill (Metric type)	L021			
WSX445L○○○○○○○	WSX445 type face mill (Metric type)	L020			
WSX445R○○○○○○○	WSX445 type face mill (Metric type)	L020			
WSX445R○○○○SA32M	WSX445 type end mill (Metric type)	L024			
WSX445UR○○○○○○○	WSX445 type face mill	L018			
WSX445UR○○○○FA20M	WSX445 type end mill	L024			
X					
XCMT○○○SVX	Insert (Class M tolerance)	A192			
XDGT1550PD○R-G○○	Insert (For BXD4000 type cutter)	K034,L176			
XDGT1550PD○R-GL○○	Insert (For BXD4000 type cutter)	K034,L176			
XDGX1750○○PD○R-GM	Insert (For AXD4000 type cutter)	K030,L161			
XDGX1750○○PDFR-GL	Insert (For AXD4000 type cutter)	K029,L161			
XDGX2270○○PDER-GLA	Insert (For AXD7000 type cutter)	K030,L169			
XDGX2270○○PDFR-GL	Insert (For AXD7000 type cutter)	K030,L169			
XNMU1607○○R-○S	Insert (For VFX5 type end mill)	K045,L188			
XNMU1909○○R-○S	Insert (For VFX6 type end mill)	K045,L192			
XNS○○	Clamp screw	N007			
XNS○○○	Clamp screw	N007			
XPGT13T3PD○R-G○	Insert (For BAP3500 type cutter)	K032			
XPMT13T3PDER-M○	Insert (For BAP3500 type cutter)	K032			
Z					
ZCMX○○○○○○ERA/B	Insert (For LER type end mill)	K035,L194			

SAFETY OF CUTTING TOOL PRODUCTS

1. Use of Cutting Tool Products

Packages of Mitsubishi products carry a safety warning label. However, tools are not labeled with detailed warning instructions. Please read the "Safety of Cutting Tool Products" in this catalog before handling cutting tool products and cemented carbide materials. Moreover, as a part of your workers' safety education, please notify the contents of the "Safety of Cutting Tool Products" to all workers.

2. Basic Characteristics of Hard Tool Materials

In Terms of "Safety of Cutting Tool Products"

Hard Tool Materials : General term for tool materials like cemented carbide alloy, cermet, ceramics, sintered CBN, sintered diamond, high speed steel and alloy steel, etc.

Physical Characteristics

Appearance : Varies depending on the type of material, e.g. gray, black, gold, etc.

Smell : None

Hardness, Specific Gravity :

Hard Tool Materials	Hardness (HV)	Specific Gravity	Hard Tool Materials	Hardness (HV)	Specific Gravity
High Speed Steel (HSS)	200—1200kg/mm ²	7—9	Sintered CBN	2000—5000kg/mm ²	3—5
Cemented Carbide	500—3000kg/mm ²	9—16	Sintered Diamond	8000—12000kg/mm ²	3—5
Cermet	500—3000kg/mm ²	5—9	Alloy Steel	200—1200kg/mm ²	7—9
Ceramics	1000—4000kg/mm ²	2—7	Diamond Electroforming Product	8000—12000kg/mm ²	3—5

Constituents

Carbide, nitride, carbon nitride, oxide, W, Ti, Al, Si, Ta, B, V and metals such as Fe, Co, Ni, Cr, Mo.

3. Safety of Cutting Tool Products

○Hard tool materials have a large specific gravity. Thus, they require special attention as heavy materials when the size or quantity is large.

○Hard tool materials generates dust and mist during grinding operations or heating. This dust and mist can be harmful to the human body when coming in contact with the eyes or skin, or if substantial quantities are swallowed. When grinding and machining, it is recommended to use local exhaust ventilation and respirators, a dust protective mask, glasses, gloves and so on. If dust makes contact with the hands, thoroughly wash the affected area with soap and water. Don't eat in the exposed area, and wash hands thoroughly before eating. Remove dust from the clothing by a cleaner or washing, but don't shake off.

○Cobalt dust can affect the skin, respiratory organs and heart through repeated or prolonged contact.

○For further information, please refer to **SDS** (Safety Data Sheet).

Home page: <http://www.mmus-carbide.com/download/safety/>

4. Handling Cutting Tool Products

○Surface conditions affect toughness of cutting tools. Therefore, use a diamond grinding wheel for finishing.

○Hard tool materials are extremely hard and brittle at the same time. Thus, they may be broken by shock and tightening with excess force.

○Hard tool materials and ferrous materials have different thermal expansion ratios. Shrinkage or swell fit products may suffer from cracks when applied temperature is higher or lower than the appropriate temperature for the tool.

○Pay special attention regarding storing hard tool materials. Toughness of hard tool materials is lowered when they corrode due to coolant and other liquid.

○When brazing hard tool materials, if the temperature is too high or too low from the melting point of the brazing material, loosening and breakage may occur.

○After regrinding cutting tools, make sure that there are no cracks.

○Machining hard tool materials on EDM may cause cracks on the surface due to remaining electrons resulting in lowering the toughness. Eliminate cracks by grinding, etc.

SUGGESTIONS ON HOW TO USE CUTTING TOOLS

Products	Hazard	Countermeasure
All Cutting Tools	◎Cutting tools have sharp cutting edges. Handling them with bare hands may cause injuries.	★ Take precautions such as wearing gloves especially when handling tools and during installation.
	◎Improper use of tools and application of inappropriate cutting conditions may cause the tool to break and be discharged from the machine providing risk of injury.	★ Ensure safety guards and goggles are used. ★ Refer to handling explanatory notes and catalogs. Use tools under recommended cutting conditions.
	◎Impact load and rapid increase of cutting resistance due to excessive wear may cause the tool to break and be expelled from the machine providing risk of injury.	★ Ensure safety guards and goggles are used. ★ Exchange tools before excessive wear occurs.
	◎Cutting tools and workpieces become extremely hot during cutting. Touching them with bare hands may cause burns.	★ Take precautions such as wearing gloves.
	◎Expelled hot chips produced in cutting produces risk of injuries and burns.	★ Ensure safety guards and goggles are used. ★ During swarf removal and machine cleaning ensure the machine is stopped and wear gloves. Please use tools, such as cutting nippers and cutting clippers.
	◎In cutting, sparks, hot chips and heat generation caused by tool breakage provides a risk of igniting a fire.	★ Avoid using cutting tools in places where there is a possibility of igniting a fire. ★ In case of using non-water soluble oil, make sure to have a fire prevention countermeasure.
	◎Using machines, chucks, and tools with poor balance at high revolutions may cause tools to break providing risk of injuries.	★ Ensure safety guards and goggles are used. ★ Check the machine for vibration, chattering, and abnormal noise.
	◎Handling machined parts with burrs using bare hands may cause injuries.	★ Wear gloves.
Indexable Inserts Type Tools	◎If inserts and spare parts are not held securely, they may become loose and be ejected producing risk of injuries.	★ Clean insert locating seat and spare parts before setting inserts. ★ Use the tool provided for setting inserts, and ensure the inserts and spare parts are clamped securely. Do not use the tool provided for things other than prescribed inserts and spare parts.
	◎Clamping inserts and spare parts too tightly by using tools such as extension pipes may cause them to break and be scattered.	★ Do not use extra tools for more leverage. Only use the tool provided.
	◎When applying high cutting speed, spare parts and inserts may be expelled due to centrifugal force. Pay special attention on each safety guideline.	★ Refer to the handling explanatory notes and catalogs. Use tools under recommended cutting conditions.
Cutters and Other Rotating Tools	◎Milling cutters have sharp edges. Handling them with bare hands may cause injuries.	★ Take precautions such as wearing gloves.
	◎Poor balance or off center revolving of tools may cause vibration and chattering which could cause the tool to break and be discharged.	★ Apply cutting speed within the range of recommended cutting conditions. ★ Adjust accuracy and balance of spindles and bearings periodically to prevent off center revolving and chattering caused by wear on these parts.
Drilling Tools	◎Through cutting in cases when the workpiece revolves may produce a disk shaped peice with sharp edges when the cutting tool breaks through.	★ Ensure safety guards and goggles are used. Also install a cover on the chuck.
	◎Drills with an extremely small diameter have a very sharp point which may puncture the skin if not handled carefully. If the drill breaks during cutting, the broken parts may be scattered.	★ Handle with care. Take precautions such as wearing gloves and goggles.
Brazed Tools	◎Weakening of the braze and breakage of inserts may cause injury.	★ Before using them, ensure they are brazed securely. ★ Do not use them under conditions which produce very high temperature.
Others	◎Machine and tools may be damaged if they are used for purposes other than the prescribed application.	★ Use them strictly for the prescribed application.

INFORMATION

This catalog completes the basic precautions for safety use of our company's products. For further information, please refer to the guideline, catalogs or contact us. We are not responsible for any accidents caused by modifying tools without our permission.